

SAT-4d

User Manual



DVB Audio Satellite Receiver

SAT-4d User Manual V1.3

Bundle Version: 1.04

April 2024

1 Contents

1	Contents.....	1
2	About this manual	4
2.1	References and hyperlinks in this PDF file	4
2.2	Tags and their meanings	4
3	For your safety	5
4	Product overview	7
4.1	About the SAT-4d	7
4.2	Rights options.....	8
4.3	Front panel.....	8
4.4	Back panel	9
5	First steps	10
5.1	Checking the delivery contents.....	10
5.2	Installing the device	10
5.3	Connecting the device.....	10
5.4	Connecting the power supply	11
5.5	Configuring the network	12
5.6	Accessing the web interface	13
5.7	General operation	13
5.7.1	Operation via web interface.....	13
5.7.2	Operation via LCD menu	13
6	Network settings	15
6.1	Configuring the interface services	15
6.2	TCP/IP: Configuring the ethernet interfaces.....	15
6.3	Monitoring the device via syslog	16
6.4	SNMP: Configuring access data for external requests.....	17
6.5	SNMP: Configuring trap managers.....	18
6.6	Ember+: Configuring access for monitoring	19
6.7	Enabling the REST API	19
6.8	NTP: Synchronizing date and time	20
7	Codec Settings	21
7.1	Input source settings.....	21
7.1.1	Creating input source profiles for TS/SAT	21
7.1.2	Creating input source profiles for TS/ASI	22
7.1.3	Creating input source profiles for TS/IP	23

7.1.4	Configuring input source profiles for TS/SRT	24
7.1.5	Creating demux configurations	24
7.1.6	Configuring input source profiles for Elementary Streams (UDP/RTP)	25
7.1.7	Creating input source profiles for Livewire	26
7.1.8	Creating input source profiles for SIP	27
7.1.9	Creating input source profiles for Icecast	28
7.1.10	Creating input source profiles for Radio	29
7.1.11	Creating input source profiles for internal storage (File).....	29
7.1.12	Creating input source profiles for audio interfaces	30
7.2	Creating codec profiles	30
7.3	Assigning source streams to a decoder	31
7.4	Configuring ancillary data	32
7.5	Defining switch criteria	33
7.6	Setting up dual streaming	34
7.7	Setting up a buffer	34
7.8	Receiving and decoding an AES67 stream	35
8	Interface settings	36
8.1	Configuring the output settings	36
8.2	Enabling the sample rate converter	36
8.3	Setting the critical level marker	37
8.4	Changing the headphone volume	38
8.5	Viewing the GPI status	38
8.6	Configuring GPO settings	38
8.7	Defining the use of the AUX interfaces.....	39
9	Audio over IP settings	40
9.1	Setting up SAP	40
9.2	Using an external clock source.....	40
9.3	Configuring Livewire settings	41
9.4	Monitoring audio via Live Listening	42
10	System settings	43
10.1	Setting up alarms	43
10.2	Entering device information	43
10.3	Setting up session timeout.....	44
10.4	Changing the title of the browser tab.....	44
10.5	Updating the firmware with a file.....	44
10.6	Checking for updates	45
10.7	Setting up rights	45
10.8	Uploading and activating an SSL certificate.....	46

10.9	Saving settings to a local file	46
10.10	Loading settings from a file	46
10.11	Generating and downloading a diagnostic report	47
10.12	Uploading a debug script	47
10.13	Rebooting the device	47
10.14	Restoring factory settings	48
10.15	Accessing the recovery mode via reset pin hole.....	48
10.16	Setting the time and date	48
10.17	Changing login data.....	49
10.18	Adapting the access for user accounts	49
11	Status information.....	50
11.1	Status LEDs	50
11.2	General overview	51
11.3	Device status	52
11.4	Ancillary data status.....	53
11.5	NTP Status	53
11.6	Internal storage status	55
11.7	Log	55
11.8	Priority of alarm messages.....	56
12	Further information.....	57
12.1	Maintenance and disposal	57
12.2	Troubleshooting, support and warranty.....	57
12.3	Manufacturer	57
13	Technical details.....	58
13.1	Specifications	58
13.2	Pin Layouts for DTE and GPIO	61
14	Certificates and declarations.....	63

2 About this manual

You can download the latest version of this user manual here:

https://download.2wcom.com/products/SAT-4d_TGXL/



2.1 References and hyperlinks in this PDF file

If you are reading this manual as a non-print version, please note that this PDF file contains bookmarks. You can navigate through the document via the content overview in your PDF viewing software if you enable bookmarks view.

All references to pages, sections, figures, and tables in the text identify a location within this PDF file. Click on the reference to jump to the referred passage in the text.

2.2 Tags and their meanings

The following signal words and signs warn you about risks and dangers:

DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	Describes precautions necessary to protect the equipment.
	Contains useful information for the user.



Warning of general danger situation



Warning of electric shock



Warning of hot surface



Warning of fire hazard

3 For your safety

The device conforms to the relevant European directives and is safely constructed. Nevertheless, some residual dangers remain. 2wcom Systems GmbH accepts no liability for any damage caused by non-observance of the safety instructions.

- Read through this user manual carefully before using the device. If you pass on the device, be sure to also include this user manual.
- Any improper use of the device and all actions on the device not described in this user manual are considered as misuse outside the statutory limits for liability of the manufacturer.
- Only operate the device if it is in a technically perfect condition. If the device or a part of it is defective, take the device out of operation. Do not repair the device yourself. In case of any damages, send the device to 2wcom immediately for inspection or dispose of it properly according to the regional disposal regulations.
- Keep the device away from unauthorized persons.



Danger from electric current!

- Plug the device into a grounded power socket only. Never remove the grounding wire/contact.
- Do not open the housing of the device by yourself. Do not touch open electrical parts.
- Dangerously high voltages are present inside the housing. Even after disconnecting the mains supply, dangerously high voltage levels may be present for a certain time.
- Do not touch the device when your hands are wet.
- Never expose the device to liquids. If any liquid gets inside the housing, immediately disconnect the device completely from the power supply. Do not continue operating the device.



Fire hazard due to overheating or electric current!

- Ensure sufficient heat dissipation during operation. Avoid the following when installing the device:
 - Non-ventilated environment, e.g. a narrow shelf or built-in cabinet
 - Extremely warm or cold place
 - Direct exposure to sunlight
 - Too high or too low temperatures
 - Extremely wet or dusty environment
- Do not cover the ventilation openings of the device to avoid heat accumulation.
- Do not operate the device in the presence of flammable gases.
- Do not place objects with open flames, such as burning candles, on the device.
- Do not place any heavy objects on the supply cord. A damaged cord can lead to fire or electric shock hazards.
- When disconnecting the supply cord, always pull on the plug, never on the cable, to avoid cord damage.



Danger from explosive atmosphere!

- Do not use the device in an explosive environment.



Warning of hot surface!

The device may heat up greatly during normal operation despite an active cooling system.

- Do not touch the surfaces of the device during or shortly after operation.



Risk of equipment damage!

- Before each use, check the housing, the front panel, the cable and the power plug for visible damage and defects (e.g. scratches, cracks, wear and tear, damaged insulation, improper plug connections or extension cables).
- If the power cord is damaged, immediately disconnect the power plug. Never use the device with a damaged power cord.
- All damaged components must be replaced immediately.
- Only use a grounded three-wire power supply cord and plug that complies with the national regulations.
- Make sure that the power socket is next to the device and readily accessible to the user.
- External devices which are connected to the device could be damaged by the device or damage the device itself if the output levels exceed the specified limits.
- Do not use corrosive detergents on the device such as benzene, thinner, alcohol or acetone. Clean the surface of the device with a soft, dry cloth only.

4 Product overview

4.1 About the SAT-4d

The SAT-4d is the perfect DVB satellite receiver for radio networks. The SAT-4d offers uncompromised and reliable reception from up to 4 of your audio programs from satellite.

High compatibility: The SAT-4d supports all known DVB-S/S2 standards and protocols for satellite reception and offers symbol rates from 1 up to 45 Msym/s. Furthermore, the SAT-4d supports transport of various private data formats such as ancillary and auxiliary (PID) data as well as contact closures (GPIO).

Redundancy: Even when satellite fails, your radio distribution is safe. Supported by 3 backups, the SAT-4d guarantees that there will always be 'Music in the air'. A range of backup sources can be selected such as Icecast/Shoutcast, TS over IP and file playback from the internal memory.

Pay as you grow: All software and hardware components are individually combinable. The scalability from up to four audio channels using software licenses gives you flexibility in planning your network and reducing your costs.

Multi-format audio coding: Another advantage is the variety of possible algorithms like MPEG1 Layer 2, MPEG2 Layer 3, most AAC profiles including the new xHE-AAC and AAC-ELDv2, OPUS, Ogg Vorbis, PCM, Enhanced aptX, Dolby Digital plus (on request) and more.

Transmission robustness: For the IP backup, Dual Streaming and Pro-MPEG FEC ensure rock-solid backup scenarios. Two hot pluggable power supplies guarantee fail-safe operation.

Smart management: For remote control, the codec offers various possibilities – HTTP, FTP, NMS, REST-API, Ember+ and SNMP.

4.2 Rights options

The following table displays an overview of the rights options that are available for your SAT-4d:


Right	Description
n Channels	Number of channels
Ravenna	Option to unlock SAP stream announcement and discovery, and PTP support
Livewire	Option to use IP streaming over Livewire
TS Decoder	Option to use transport stream over IP using UDP/RTP, unicast/multicast for decoders
SRT Decoder	Option to use SRT or RIST for decoders
n Dolby Decoder	Number of Dolby decoders
Live Listening	Option to monitor input sources of the encoder and decoder as well as audio outputs via the web interface or Icecast.
ES Input	Option to use elementary streams as an input source
Icecast Input	Option to use Icecast as an input source
File Input	Option to use a file from the internal storage as an input source
BISS	Option to use BISS descrambling (Basic Interoperable Scrambling System) for TS/SAT and TS/ASI input sources

4.3 Front panel



- 1 **Headphone:** 6.3 mm / 1/4" socket for the connection of headphones
- 2 **LCD Screen:** Illuminated LCD screen, graphical, 264x64 pixels
- 3 **[Warning] LED:** LED indicator; will be red if alarm is triggered
- 4 **[Input] LED:** LED indicator; will correspond to the sum of the alarm status for the inputs:
 - off if no input alarms are enabled
 - green if input alarms are enabled and all inputs are OK
 - yellow if one or more inputs are bad but at least one is good
 - red if all inputs are bad
- 5 **[Output] LED:** LED indicator; will correspond to the sum of the alarm status for the outputs.
 - off if no output alarms are enabled
 - green if output alarms output alarms are enabled and all outputs are OK
 - yellow if one or more outputs are bad, but at least one is good
 - red if all outputs are bad
- 6 **[Power] LED:** LED indicator:
 - green if all power supply cords are connected and the power supply is OK.
 - flashes (green/red) if only one power supply cord is connected and the power supply is OK (only when there is more than one power supply)
- 7 **Reset pin hole:** Recessed button for resetting the device (warm start and recovery mode)
- 8 **Jog wheel:** Jog wheel for the device operation via the LCD screen on the device

4.4 Back panel




- 1 **Power supply unit:** Mains supply voltage IEC socket.
Optional redundant power supply through a second power supply unit:
 - Option 1: standardized IEC hot-swappable power supply connector; 90-260 V, 47-63 Hz; automatic switchover.
 - Option 2: power supply 48 V DC.
 Combination of power supply 230 V AC and 48 V DC is possible
- 2 **Grounding stud:** This stud can be used to connect a grounding system if necessary.
- 3 **[Ctrl]:** RJ-45 connector, 10/100/1000 Base-T interface for controlling and monitoring the device via Ethernet. The device can communicate with the IP network and can be configured via the integrated web interface using an internet browser. The LEDs show the link status (green, active if a physical network connection exists) and the activity status (yellow, active if data communication is active).
- 4 **[Data]:** 2x RJ-45 connector; 10/100/1000 Base-T interface for two redundant outputs for data, audio and GPIO transmission via ethernet.
- 5 **[DTE]:** 15 pole D-Sub male connector for serial RS-232C data communication, e.g. private data, MPEG ancillary data, UECP/RDS (acc. to TR 101 154). Use a serial breakout cable to provide each input and output with a serial interface.
- 6 **[D OUT][A-L OUT]:** AES/EBU male interface for the output of digital audio. Integrated XLR male socket; output of the left channel of the analog audio signal, balanced < 20 Ω.
- 7 **[D OUT][A-R OUT]:** AES/EBU male interface for the output of digital audio. Integrated XLR male socket; output of the right channel of the analog audio signal, balanced < 20 Ω.
- 8 **[RF]:** Antenna input for SAT tuner.
- 9 **[AUX]:** (optional) signal output depending on built in hardware component.
- 10 **[SYNC/ AUX]:** (optional) connector for SFN synchronization (GPS input) or optional ASI input.
- 11 **[GPIO]:** 26-pole D-Sub male connector; combined connector for inputs (GPI) and outputs (GPO).
- 12 **[USB]:** USB 2.0 interface for service, configuration and firmware.

5 First steps

5.1 Checking the delivery contents

Use the following list to check the completeness of delivery. The delivery contents may vary in exceptional cases.



SAT-4d



Link to product data



Power cord



Network patch cable

5.2 Installing the device

For the device to operate safely, note the following regarding the location:

- Mount the device securely and stable in a 19-inch rack designed for this purpose.
- Avoid direct sunlight, direct proximity to radiators and air conditioners, dust, water and chemicals
- When setting up the device, make sure that it is placed at a suitable viewing angle to the displays and that the device has sufficient heat dissipation.

5.3 Connecting the device

Before connecting the device to the power supply, first connect the inputs and outputs of the device to the corresponding connectors:

1. For output of the digital/analog audio signal, connect the signal outputs to [D OUT]/[A-L/R OUT].
 2. Connect a network patch cable to [Ctrl] and to your existing network.
 3. Connect network patch cables to [Data] and to your existing network.
 4. Connect the antenna signal to [RF].
 5. For GPIO communication, connect a serial cable to [GPIO]. The pin layout is displayed in the technical details.
 6. For serial RS232C data communication, connect a serial breakout cable to [DTE]. The pin layout is displayed in the technical details.
 7. Optionally, connect the [SYNC/AUX] and [AUX] interfaces if needed.
 8. Use the headphone output for monitoring the output audio signals.
- ✓ You have connected the device. Continue with connecting the power supply.

5.4 Connecting the power supply

NOTICE Risk of equipment damage!


- Make sure that the device and the contained cords are compatible to the domestic line voltage and frequency!

Optionally, the device comes with 2 exchangeable plug-in power supply units which can be equipped with different redundant power supply connectors: either IEC sockets or Neutrik powerCON sockets.



If the device is equipped with a primary and a secondary power supply, then the primary power supply is used. If the primary power supply fails, then the device promptly switches to the secondary power supply and the status changes immediately on the **Device** status page. If the secondary power supply fails, then the device does not need to switch the power supply source and it takes at least 1 minute for the status to update on the **Device** status page.

IEC socket



IEC socket: 230 V AC, 90-260 V AC, 47-63 Hz

- Connect the power supply cord fully to the IEC socket at the back panel of the device and to an independent mains power outlet.
- ✓ You have connected the power supply to the device. The [Power] LED is green if both power supply cords are connected. The [Power] LED flashes green/red if only one power supply cord is connected.

Neutrik powerCON socket






48 V DC Neutrik powerCON socket with aut. switchover (NAC3MPA 1) and Neutrik powerCON connector (NAC3FCA)

NOTE: The corresponding power cords are not part of the delivery contents!


To prepare and connect the Neutrick powercon connector:

1. Slide the clamping sleeve and collet onto the cable.
2. Remove part of the insulation.
3. Insert the wires into the clamping holes on the inset and fasten them with screw and clamping plate using a screwdriver.



If you use the voltage of 48+ V and 0 V, fasten the +48 V wire to **L** in the connector.
If you use the voltage 0 V and 48 V, fasten the 0 V wire to **L** in the connector.

4. Push the inset and collet into the housing (observe guide ribs and guide slot).



5. Tighten the clamping sleeve with a wrench.
 6. Connect the power supply cord fully to the powerCON socket at the back panel of the device and to an independent mains power outlet.
- ✓ You have connected the power supply to the device. The [Power] LED is green if both power supply cords are connected. The [Power] LED flashes green/red if only one power supply cord is connected.

5.5 Configuring the network

NOTICE False connection of the Ethernet interfaces will lead to incorrect operation!

- Use the [Data] interfaces only for data transfer.
- Use the [Ctrl] interface only for the access to the device via the web interface and for SNMP.

To transfer data over IP and access the device via the web interface, you must connect the device to your IP network.

For the [Ctrl] interface, DHCP is enabled by default. When you connect the device to your DHCP-enabled network, it will automatically get the IP configuration for the [Ctrl] interface. To view the obtained IP address, turn the jog wheel to the left to see the “System Info” display. Here you will find the obtained IP address and further system information.

To connect the device to your IP network and change the IP setup via the LCD menu:

1. Push the jog wheel to enter the configuration menu.
 2. Turn the jog wheel to focus the **Network** tab and push the jog wheel.
 3. Push the jog wheel to enter the menu for the [Ctrl] interface.
 4. Configure the settings for your existing IP network (IP address, netmask, gateway etc.). Consult the responsible network administrator if applicable.
 5. Turn the jog wheel until the **Save** menu item is selected and push the jog wheel.
 6. In the dialog window, select **Yes** to save the settings and restart the device.
- ✓ The device is now connected to the IP network.

5.6 Accessing the web interface

The device can be fully operated via the integrated web interface using an internet browser. For this purpose, use a computer that is connected to the same IP network that the device is connected to.

Requirement: You have already connected the [Ctrl] interface to the network.

1. Access the web interface by entering the IP address of the device into a web browser.
 - A login screen appears.
2. Enter the username and password.
- ✓ The main page of the web interface appears.

The default login data (case sensitive) are:

- For read-only access: **user / user**
- For full access: **manager / manager** or **admin / admin**



Change the login data as soon as possible to avoid unauthorized access to the SAT-4d and document the login data in a safe place.

5.7 General operation

5.7.1 Operation via web interface

The SAT-4d has an integrated web interface. You can make all configurations and operations using a web browser.

Note the following rules when operating the device via web interface:

- If you want to keep any changes made in the configuration of the device, click the corresponding **Save** button.
The changes in each block must be saved individually. If you changed data in several blocks or tabs, click the **Save** button under each block to save all changed data. Otherwise, any unsaved block will be reset to the previously saved status when leaving the page.
- If you do not want to keep the changes, leave the page without saving or reload the page.
- Use a decimal point as the decimal separator in numbers in the input fields (i.e. “6.5” for “six and a half”).

5.7.2 Operation via LCD menu

Some basic functions of the device can be operated via the LCD menu and jog wheel.

The display has 2 main menus:


- Status menu (turn jog wheel left or right)
- Configuration menu (push jog wheel)

After a warm or cold start of the device, the display shows the default screen of the status menu. When you navigate in the LCD menu, the display returns to the Status Overview after few minutes of inactivity.

Note the following when operating the device via the LCD menu:

- To switch from the status menu to the configuration menu, push jog wheel.
- To move the focus in the menu structure, turn jog wheel.
- To open a menu tab, focus the tab and push jog wheel.
- To select a configurable menu entry, focus the entry and push jog wheel.
- To configure the selected menu entry, turn jog wheel.
- To confirm changes in a menu entry, push jog wheel.
- To return to the previous menu level, select <<.

Navigation structure



6 Network settings

6.1 Configuring the interface services

For each ethernet interface, you can select the services by which the interface can receive and send data.

Services

Interface services

	HTTP (Web)	HTTPS (Web)	SSH (SFTP)	SNMP	Ember+	Streaming Data
Ctrl:	<input checked="" type="checkbox"/>					
Data 1:	<input type="checkbox"/>	<input checked="" type="checkbox"/>				
Data 2:	<input type="checkbox"/>	<input checked="" type="checkbox"/>				

SNMP: Only affects get and set commands, traps are not affected

Save

To select the supported services.

1. Navigate to the page **Services**.
 2. For each individual interface, define which data can be received and sent.
 3. Click **Save**.
- ✓ The interfaces now only support the selected services.

6.2 TCP/IP: Configuring the ethernet interfaces

The SAT-4d has several Ethernet interfaces: 1 for configuration and the others for data exchange. Configure the interfaces for data transmission.

NOTICE False connection of the Ethernet interfaces will lead to incorrect operation!

- Use the [Data] interfaces only for data transfer.
- Use the [Ctrl] interface only for the access to the device via the web interface and for SNMP.

TCP/IP

DNS Server

Primary: Routing: OFF

Secondary: Routing Interface:

Proxy Server

Enable proxy:

Host: Port:

Note: The Proxy server will only be used for Icecast input streams

Save

Interface settings

Link	Interface name	Mac address	VLAN	DHCP	IP address	Subnetmask	Gateway	Speed:	Mode:
●	Ctrl	00:11:99:00:94:1E	<input type="checkbox"/> OFF	<input checked="" type="checkbox"/> ON	192.168.100.238	255.255.240.0	192.168.96.1	auto	full duplex
●	Data 1	00:11:99:00:94:1F	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> OFF	192.168.100.250	255.255.240.0	192.168.96.1	auto	full duplex
			ID				Priority		
			200	<input type="checkbox"/> OFF	192.168.200.100	255.255.255.0	0.0.0.0	0	- +
●	Data 2	00:11:99:00:94:20	<input type="checkbox"/> OFF	<input type="checkbox"/> OFF	10.80.118.173	255.255.255.0	10.80.118.177	auto	full duplex

Save

To configure the ethernet interfaces:

1. Navigate to the page **TCP/IP**.
2. Configure the parameters for the DNS Server, Ctrl and Data interfaces.



The necessary address settings depend on the individual network and should be assigned by the responsible network administrator, if applicable.


3. Click **Save**.
- ✓ The ethernet interfaces are now configured.

Parameters

Primary	Enter the IP address of the primary domain name server (DNS).
Secondary	Enter the IP address of the secondary domain name server (DNS).
Routing	Enable the Routing, which enables the DNS server to send and answer the requests over different [Data] interfaces.
VLAN	Enable VLAN and enter a VLAN ID (1-4095).
Priority	Assign a priority (1-7) to this stream to add a priority code point (PCP) according to the IEEE 802.1Q specification. Select 0 to disable the priority and use best-effort delivery.
DHCP	Enable dynamic host configuration protocol (DHCP) which enables the device to get an IP address automatically.
IP Address	If DHCP is disabled, then assign an IP address to the interface.
Subnetmask	Enter the subnetmask for the IP address.
Gateway	Enter the address of the local system that is used for the internet access (e.g. the router).
DNS Server	Enter the IP address of the DNS server used.
Speed	Set the network connection speed in Mbps or select Auto .

6.3 Monitoring the device via syslog

In addition to saving information about events in the log, you can also send them to a syslog server. Syslog eases monitoring the SAT-4d.



To send event information to a syslog server:

1. Navigate to the page **Syslog**.
 2. Enable at least one of the servers.
 3. Configure the parameters.
 4. Click **Save**.
- ✓ The SAT-4d now sends event information to the syslog server(s).

Parameters

IP address	Enter the IP address of the syslog server.
Port	Enter the port number.

- Protocol** Select the protocol to be used.
- Lowest level** Select the lowest level of a message that will be sent to the syslog server. For more information, see 10.8 Priority of alarm messages.
- Interface** Select the [Data] interface to be used.
- VLAN** If the selected [Data] interface is an interface with VLAN, then select the VLAN to be used.

6.4 SNMP: Configuring access data for external requests

You can configure access data (read community/write community) that is necessary for external SNMP requests to the SAT-4d.

SNMP (Simple Network Management Protocol) is a protocol used for managing and monitoring network devices. SNMP requests can be used to retrieve information such as the SAT-4d's current settings and performance metrics. This information can be used to diagnose problems and optimize network performance. SNMP requests can also be used to configure the SAT-4d remotely, allowing administrators to adjust settings.



For the SNMP manager tool to operate correctly, it requires the specific MIB files. These MIB files must be compiled by your SNMP manager tool. You can save the MIB files in the block **MIB File**.


1. Navigate to the page **External APIs**.
 2. Click on the tab **SNMP**.
 3. Select the protocol version in the block **SNMP Protocol**.
 4. Configure the parameters in the block **Read/Write Community** or **SNMP3 / Security**. The parameters differ depending on the selected protocol version.
 5. Click **Save**.
- ✓ You have configured the access data for external SNMP requests.

Parameters

- Read Community** Enter SNMP access data for the external read-only SNMP access to the device.
- Write Community** Enter SNMP access data for the external write SNMP access to the device.
- Read/Write user** Enter user name and password for the external write SNMP access to the device.
- Read/Write user** Enter user name and password for the external read-only SNMP access to the device.
- Security protocols** Select an authentication protocol and a privacy protocol.

6.5 SNMP: Configuring trap managers

As part of the monitoring function, the device can send SNMP traps to the defined IP addresses of the SNMP managers. SNMP traps are messages that are sent from a network device to a central management system when a specific event or condition occurs. SNMP traps are used as a means of notifying network administrators of important events, such as errors or performance issues, allowing them to take corrective action as needed. You can also readout the settings via SNMP Get.



The screenshot shows the SNMP configuration page with the following sections:

- Settings:** Protocol version: SNMPv2c
- Trap Configuration:** Location of table indices (reboot needed): OID (default)
- Read/Write Community:**
 - 1. Read community: public
 - 2. Read community: public
 - 1. Write community: private
 - 2. Write community: private
- Trap Manager:**

	Enable	Version	IP / Domain Name	Interface	VLAN	Port
1	<input type="radio"/> OFF	V2		ctrl	--	162
2	<input type="radio"/> OFF	V2		ctrl	--	162
3	<input type="radio"/> OFF	V2		ctrl	--	162
4	<input type="radio"/> OFF	V2		ctrl	--	162
- MIB File:**
 - Version:
 - Download: [SNMP MIB](#)



For the SNMP manager tool to operate correctly, it requires the specific MIB files. These MIB files must be compiled by your SNMP manager tool. You can save the MIB files in the block **MIB File**.

1. Navigate to the page **External APIs**.
 2. Click on the tab **SNMP**.
 3. Select the protocol version in the block **SNMP Protocol**.
 4. Select the location of the table indices in the block **Trap Configuration**: OID or OID plus additional index.
 5. Configure the parameters in the block **Trap Manager**.
 6. Click **Save**.
- ✓ You have configured the trap managers. If you changed the location of table indices, the SAT-4d must reboot. Each enabled trap is sent once at startup for initialization.

Parameters

Version	Select the format version of the SNMP traps.
IP or Domain Name	Enter the IP address or domain name of the trap receiver.
Port	Enter the port number.

6.6 Ember+: Configuring access for monitoring

As part of the monitoring and remote-control function, the device is capable to be controlled via the Ember+ protocol.



1. Navigate to the page **External APIs**.
 2. Click on the tab **Ember+**.
 3. Configure the parameters in the block **Settings**.
 4. Click **Save**.
- ✓ You have configured the Ember+ access.

Parameters

Mode	Select the mode from the dropdown menu.
Timeout	Enter the value for interval in seconds for a timeout.
Interface	Select an Ethernet interface from the dropdown menu.
Port	Enter the port number for the connection.

6.7 Enabling the REST API

A REST API is a standardized method for software applications to communicate over the internet. It operates based on REST principles, using HTTP requests and responses. The REST API enables seamless integration with other applications. It simplifies control through familiar HTTP methods, offers remote management, and facilitates automation, real-time monitoring, scalability, and extensibility. With help of the REST API, you can automate tasks and efficiently manage your audio codec system.


2wcom's REST API is compliant to Open API 3.0. For more information on Open API 3.0, refer to the official documentation: <https://swagger.io/specification/>

To enable the REST API:

1. Navigate to the page **External API**.
 2. Select the tab **REST API**.
 3. Set the switch **Enabled** to **ON**.
 4. Click **Save**.
 5. Download the file **openapi.json** from the page.
- ✓ You have now access to the REST API of the SAT-4d. For detailed information for developers, refer to the API documentation: https://download.2wcom.com/general/2WCOM_REST_API.pdf

6.8 NTP: Synchronizing date and time

The SAT-4d can automatically synchronize its date and time with an external NTP (Network Time Protocol) server. The configurable parameters on this page may differ depending on the activated rights.



1. Navigate to the page **NTP**.
 2. Configure the parameters.
 3. Click **Save**.
- ✓ You have synchronized the date and time with an external NTP server.

Parameters

Synchronization	Start or stop the synchronization with the NTP server.
Bind to interface	To bind the NTP synchronization to a specific IP interface, set the switch to ON . Select the [data] interface and VLAN.
QoS DSCP	Select the quality of service (QoS). The selected packet will be prioritized.
NTP Quality Rating	<p>Select the quality of the NTP server.</p> <p>Low: Event logging, device time synchronization.</p> <p>Medium: For NTP servers that are accessed through the Internet and are used as External Clock source.</p> <p>High: For Stratum 1 NTP servers that are connected locally and are used as External Clock source. (SPN)</p> <p>For Medium and High settings, NTP will be rated as valid once the clock discipline algorithm has converged to acceptable RMS offset and skew values. For the Low setting, NTP becomes valid much quicker with reduced accuracy, however it will increase over time.</p>
Enable expert settings	Set the switch to ON to show further parameters.
1. NTP Server	Enter the IP address or network name of the first NTP server to be used.
2.-4. NTP Server	Enter the IP addresses or network names of the 2nd, 3rd and 4th NTP servers to be used.

7 Codec Settings

7.1 Input source settings

7.1.1 Creating input source profiles for TS/SAT

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 TS/SAT	TS/SAT – Transport stream over satellite (optional: <i>Sat Tuner</i> right)	[RF Sat]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
 7. Create a demux configuration that uses this input source profile as a source. (See 6.1.5 Creating demux configurations)
- ✓ You have created an input source profile.

Parameters

Name	Enter the name of the stream for better reference.
RF input	Select the RF input to be used.
DVB standard	Select the DVB standard.
Modulation	Select the modulation type of the signal to be received.
Frequency input method	Choose whether you want to enter the L-Band frequency or the transponder frequency and LNB data. The transponder frequency will be automatically translated into the corresponding L-Band frequency.
L-Band Frequency	Enter the L-Band frequency of the channel to be received.
Transponder Frequency	Enter the transponder frequency of the channel to be received. Click LNB Config to enter the LNB information.
Symbol rate	Enter the symbol rate used by the transponder.
Roll-Off	Select the roll-off factor used by the receiver filter.
Polarization	Select either horizontal or vertical polarization used by the transponder.
Frequency Range	22 kHz signal used to tell the LNB via Digital Satellite Equipment Control (DiSEqC) to pass on lower band (22 kHz off) or upper band (22 kHz on) signals.
Pilot Mode	If the standard DBV-S2 is used, then select whether a pilot tone is used or not. If unknown, select Auto .
FEC	Select the FEC settings used by the transponder. If unknown, select Auto . This may result in slightly increased tuning times.
BISS descrambling	Enable BISS descrambling. BISS is a method for securing and scrambling media transmission. Components are scrambled by a Session Word that is either clear or

encrypted. The clear or encrypted session word is transmitted out of band to the receivers.

- BISS mode** Select the BISS mode: mode 1 (clear) or mode E (encrypted).
- Clear Session Word** If mode 1 (clear) is selected, then enter the clear session word.
- Injected ID** If mode E (encrypted) is selected, then enter the injected ID for decryption of the encrypted session word.
- Enrcrypted Session Word** If mode E (encrypted) is selected, then enter the encrypted session word.

7.1.2 Creating input source profiles for TS/ASI

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 TS/ASI	TS/ASI – Transport stream over ASI input	[SYNC/AUX]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
 7. Create a demux configuration that uses this input source profile as a source. (See 6.1.5 Creating demux configurations)
- ✓ You have created an input source profile.

Parameters

- Name** Enter the name of the stream for better reference.
- BISS descrambling** Enable BISS descrambling. BISS is a method for securing and scrambling media transmission. Components are scrambled by a Session Word that is either clear or encrypted. The clear or encrypted session word is transmitted out of band to the receivers.
- BISS mode** Select the BISS mode: clear or encrypted.
- Clear Session Word** If mode 1 (clear) is selected, then enter the clear session word.
- Injected ID** If mode E (encrypted) is selected, then enter the injected ID for decryption of the encrypted session word.
- Enrcrypted Session Word** If mode E (encrypted) is selected, then enter the encrypted session word.

7.1.3 Creating input source profiles for TS/IP

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 TS/IP	TS/IP – Transport stream over IP using UDP/RTP, Unicast/Multicast (optional: “TS Decoder” right)	[Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
 7. Create a demux configuration that uses this input source profile as a source. (See 6.1.5 Creating demux configurations)
- ✓ You have created an input source profile.

Parameters

Name	Enter the name of the stream for better reference.
IP type	Select Unicast/Multicast.
Multicast IP	Enter the IP for Multicast, if selected as IP type.
Port	Sender UDP port (the same as set in the encoder settings for output streaming)
IP interface	Select the interface for the input signal.
Protocol	Select the MPEG2 transport stream encapsulation.
Packet reorder/ de jitter delay	<p>The de jitter buffer for IP transforms the variable delay into a fixed delay. It holds the first packet received for a period of time before it sends it out to the decoder. This time period is necessary for reordering the packets as well as to compensate the jitter and optionally to apply FEC correction and/or to combine it with the second, dual streaming input.</p> <p>Enter the value for this holding period in ms.</p> <p>NOTE: The delay time of the input source must not exceed 200 ms if the sample rate is 192 kHz.</p>
RIST	Enable RIST to recover lost packets by resending them.
FEC Mode	Configure the FEC mode depending on the sample rate and the acceptable value for delay. For more information about the delay values, see 6.7 Setting up a buffer.
FEC column/row port offset	<p>Enter the offset to the main destination port the data should be sent to. For example, if the main port is 5004, the value "2" for FEC column port offset means that the port is then 5006 (5004 + 2).</p> <p>If you do not want to use this offset, enter "0".</p>
Dual streaming	If dual streaming is enabled, configure the IP parameters. You can set up the same or different [Data] sources for the Ethernet input.

7.1.4 Configuring input source profiles for TS/SRT

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 TS/SRT	TS/SRT – Transport stream over IP using SRT (optional: “TS Decoder” and “SRT Decoder” rights)	[Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
 7. Create a demux configuration that uses this input source profile as a source. (See 6.1.5 Creating demux configurations)
- ✓ You have created an input source profile.

Parameters

Name	Enter the name of the stream for better reference.
Mode	Select whether you want to use SRT in listener or caller mode.
Port	Specify the port number for SRT connection.
IP interface	Select the interface for the input signal.
Latency	Define the time interval for the latency before the SAT-4d starts to decode the signal distributed via SRT protocol.
Encryption	If the input stream is protected by AES encryption, enable end-to-end encryption.
Maximum reorder tolerance	Enter the maximum number of packets that should be reordered.
Passphrase	Enter the password used to secure the SRT stream.

7.1.5 Creating demux configurations

To use an input source profile that is TS-based, you must first create a corresponding demux configuration.

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the tab of a TS-based input source.
 3. In the block **Demux Configurations**, select the tab **Audio** to use the audio and optionally the ancillary data of a stream. Select the tab **Data** to only use the ancillary data of a stream. For more information, see 6.4 Configuring ancillary data.
 4. To create a new demux configuration, click .
 5. To configure the demux configuration, click **Edit**.
 6. Configure the parameters.
 7. Click **Save**.
- ✓ You have created a demux configuration.

Parameters

TS source	Select the source for the demultiplexer configuration profile in the dropdown menu.
Configuration mode	Select the configuration mode. <ul style="list-style-type: none"> • Manual/PID: Enter the specific audio PID and a name for better reference. • Service from list (fixed PID): Refresh the service list. Select the service and audio track. • Service from list (auto PID): Refresh the service list. Select the service. This mode is used for services that switch to another audio track at times. In that case, the SAT-4d automatically switches to the new audio PID.
Encapsulation mode	Select an encapsulation mode: Multiprotocol Encapsulation or Packetized Elementary Stream.
Audio sync mode	Select the audio sync mode: Buffer level: synchronization with the rate of the incoming data PCR: synchronization with the PCR PID. This is more precise.
Decoder type	Predefine the codec type for the decoder by choosing the audio codec or selecting "Automatic" from the dropdown menu.
Buffer [ms]	Enter a value for the audio buffer.
Gain	Enter a value for the gain of this input source.
Ancillary data decoding	If the input stream of the decoder contains ancillary data, the SAT-4d can forward them to the corresponding outputs. If ancillary data are enabled, private data cannot be enabled.
GPIO tunneling	Enable or disable GPIO tunneling for GPIO switch between encoder and decoder.
Private data	If private data is enabled, enter the data PID and select the configuration mode from the dropdown menu. If private data are enabled, ancillary data cannot be enabled.

7.1.6 Configuring input source profiles for Elementary Streams (UDP/RTP)

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 Elementary Streams	RTP Elementary stream over IP using Unicast/Multicast	[Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Name	Enter the name of the stream for better reference.
IP type	Select Unicast/Multicast.
Multicast IP	Enter the IP for Multicast, if selected as IP type.

Port	Sender UDP port (the same as set in the encoder settings for output streaming)
IP interface	Select the interface for the input signal.
Protocol	Select the MPEG2 transport stream encapsulation.
Packet reorder/ de jitter delay	The de jitter buffer for IP transforms the variable delay into a fixed delay. It holds the first packet received for a period of time before it sends it out to the decoder. This time period is necessary for reordering the packets as well as to compensate the jitter and optionally to apply FEC correction and/or to combine it with the second, dual streaming input. Enter the value for this holding period in ms.
RIST	Enable RIST to recover lost packets by resending them.
Decoder type	Predefine the codec type for the decoder by choosing the audio codec or selecting "Automatic" from the dropdown menu.
Synchronous Payout/SFN	Enable Synchronous Payout using SFN or enter a buffer size [ms].
Buffer [ms]	Enter a value for audio buffer.
Gain	Set the source-specific gain. This is useful if the level of this source is either higher or lower than the levels of the other sources in the decoder chain (main - backup).
Ancillary data decoding	If the input stream of the decoder contains ancillary data, the SAT-4d can forward them to the [DTE] outputs.
GPIO tunneling	Enable GPIO Tunneling for GPIO switch between encoder and decoder.
FEC Mode	Configure the FEC mode depending on the sample rate and the acceptable value for delay. For more information about the delay values, see 6.7 Setting up a buffer.
FEC column/row port offset	Enter the offset to the main destination port the data should be sent to. For example, if the main port is 5004, the value "2" for FEC column port offset means that the port is then 5006 (5004 + 2). If you do not want to use this offset, enter "0".
Dual streaming	If dual streaming is enabled, configure the IP parameters. You can set up the same or different [Data] sources for the Ethernet input.

If the right *Ravenna* is activated, then you can configure the settings automatically by using the *Ravenna* protocol. For this function, first configure the SAP service. Available streams will then be displayed in the dropdown menu **available streams**. Copy the settings into the input fields by clicking **Copy/use selected stream settings**.

7.1.7 Creating input source profiles for Livewire



This option is only available if the right *Livewire* is enabled.

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 Livewire	IP Streaming over Livewire (optional: "Livewire" right)	[Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
3. To create a configuration profile, click .

4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Livewire Source	In this menu, available advertised Livewire streams will be displayed and can be selected for automatic configuration. To enter the Livewire settings manually, select Manual .
Source Channel	Enter a number (16 bit, in the range of 0...65535) describing a stream/channel.
Source Port	Specify the port number for Livewire connection.
Source Interface	Select the [Data] interface for Livewire connection.
Gain	Specify gain for the Livewire source.

7.1.8 Creating input source profiles for SIP



This option is only available if the right *EBU Tech 3326* is enabled.

The SAT-4d supports Audio IP streaming using SIP (Session Initiation Protocol). You can use an SIP connection for bidirectional data flows between encoder and decoder: either directly or via the [Data] interfaces or over a server (registrar).

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
	Stream over IP using SIP – Session Initiation Protocol (optional: “EBU Tech 3326” right)	[Audio IN] [Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Registrar	Enter the Internet domain name of a SIP server if you want the connection to be established over a SIP server.
Proxy	If Use proxy is enabled, specify the IP address.
Phone number	Enter your phone number for registration with a SIP server.
Display name	Assign a name to the SIP server for better reference.
Username	Enter your username for registration with a SIP server.
Password	Enter your password for registration with a SIP server.

Interface	For different accounts, you can use different [Data] interfaces or the same interface to set up the connection.
Packet reorder / dejitter delay	The dejitter buffer for IP transforms the variable delay into a fixed delay. It holds the first packet received for a period of time before it sends it out to the decoder. This time period is necessary for reordering the packets as well as to compensate the jitter and optionally to apply FEC correction and/or to combine it with the second, dual streaming input. Enter the value for this holding period in ms.
Expires	Enter the interval in seconds for the registration renewal.
Connection timeout	Enter the interval in seconds for disconnection if there is no incoming audio signal.
Mono mix mode	Choose Left, Right or Downmix (send audio stream).
RTP port	If Auto-configure RTP port is disabled, specify the port number.
RIST	Enable RIST to recover lost packets by resending them. You can enter a limit for the bandwidth used by the stream including re-sent packets.
Buffer	Enter a value for audio buffer.

7.1.9 Creating input source profiles for Icecast

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 Icecast	Stream over IP using TCP (Icecast/Shoutcast)	[Data]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Name	Assign a name to the Icecast server for better reference.
URL	Enter the URL of an Icecast server in the local network or the internet, e.g. "192.168.99.131" or "www.backup-audio.com".
IP Interface	Select the [Data] interface for the audio stream input.
Buffer	Enter a value for audio buffer.
Ancillary data	To add ancillary serial data to the stream, activate the switch.
GPIO tunneling	Enable GPIO tunneling for GPIO switch between encoder and decoder.

7.1.10 Creating input source profiles for Radio

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 Radio	Audio over FM or DAB tuner.	[RF]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Name	Assign a name to the configuration profile for better reference.
RF Input	Select the RF input to be used.
Tuner type	Select the tuner type.
FM Frequency	Enter the frequency of the input signal.
FM Mode	Select the FM mode. Auto switches between stereo and mono depending on the signal quality.
FM Deemphasis	Select the deemphasis to reverse previously added emphasis on the signal.

7.1.11 Creating input source profiles for internal storage (File)

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 File	Files from internal storage	Internal storage (eMMC, optional SSD)

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Name	Assign a name to the configuration profile for better reference.
File	Select an audio file in the dropdown menu.
Buffer	Enter a value for audio buffer.

Gain Set the source-specific gain. This is useful if the level of this source is either higher or lower than the levels of the other sources in the decoder chain (main - backup).

7.1.12 Creating input source profiles for audio interfaces

You can create an input source profile and use it for decoding.

Input Source	Description	Source Interface
 XLR	Digital (AES/EBU) or analog audio over XLR connector	[D IN] [A IN]
 AES67	Digital (AES67) audio	[D IN]

To create a new configuration profile for an input source:

1. Navigate to the page **Codec**.
 2. In the block **Input Sources**, select the input source for which you want to create a configuration profile.
 3. To create a configuration profile, click .
 4. To set up the new configuration profile, click **Edit**.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created an input source profile.

Parameters

Name Assign a name to the configuration profile for better reference.

Ancillary data source Select the source for ancillary data in the dropdown menu.

7.2 Creating codec profiles

You can create codec profiles to assign them to SRT input source profiles.

1. Navigate to the page **Codec**.
 2. Click on the tab **Profiles**. This tab is only visible if the right *SRT* is activated.
 3. To create a new codec profile, click .
 4. To set up the new codec profile, click **Edit**.
 - A dialog window opens.
 5. Configure the parameters.
 6. Click **Save**.
- ✓ You have created and edited a codec profile.

Parameters

Name Assign a name to the codec profile for better reference.

Encoder format Select the encoder format. Different settings are configurable depending on the selected encoder format.

Frame size Select the required frame size.


Audio mode Select the audio mode in the dropdown menu.

Sampling rate Set up sampling rate in the dropdown menu. The sampling rate for Livewire can only be configured for 48 kHz.
For some 2wcom devices, the sampling rate is set to 192,000 Hz.

Sampling width	Set up sampling width in the dropdown menu in the range of 16-24 bits depending on the selected encoder format.
Endianness	Select the endianness (order of bytes).
Bitrate	Select the bit rate in the dropdown menu depending on the chosen audio mode. For some encoder formats, this field shows the calculated bitrate depending on the selected settings.
GPIO Tunneling	Enable GPIO tunneling for GPIO switch between encoder and decoder.

7.3 Assigning source streams to a decoder

For each audio output, you can activate up to 4 input streams for decoding and assign one of them to the "Main Source". The remaining streams are alternative backups for decoding. The decoder receives and processes all enabled input sources from the encoder but only outputs the highest-priority audio signal that is error-free. The priorities of the streams are as follows: main source, backup 1, backup 2, backup 3.



Prerequisite: You have already created input source profiles (see 6.1 Input source settings).

To assign source streams to a decoder:

1. Navigate to the Codec page.
 2. Click on the tab **Decoder** tab.
 3. Under **Source Assignment**, activate an input signal in the **Main** column by setting the switch to **ON**.
 4. To assign an input source profile to the main source, select it in the dropdown menu. Alternatively, drag and drop the input source profile into the field.
 5. Assign up to 3 backup sources following the same principle.
 6. Choose between **Active** or **Standby** mode for your backup sources. This setting determines how the decoder handles these sources.

When a backup source is set to Active mode, the decoder continuously processes it. This ensures that the backup source is readily available for immediate use. It offers quick switching to the backup source when required.

In Standby mode, the decoder still receives the backup source, but it remains in a dormant state, consuming fewer system resources. The decoder will only start processing the standby source when it's needed. While Standby mode conserves resources, it may introduce a slight delay when switching to the standby source due to the initial processing time.
 7. Optionally, disable **Full automatic backup switching** to gain more control over the source switching. Click on the arrows between the sources to prevent a backup from automatically switching back to the input of higher priority, even if it improves in quality. This prevents unwanted back-and-forth switching between unstable sources.
 8. Click **Save**.
- ✓ The decoder now processes the main and backup sources. Continue with defining switch criteria for the main and backup sources (see 6.5 Defining switch criteria).



You can decode and play files from the internal storage. This option is recommended as an advanced redundancy for backup sources in case of input failure.



You can use XLR audio inputs as a backup source fed from an external device or for a loopback test.

7.4 Configuring ancillary data

You can configure ancillary data and add them to the outputs.

Ancillary Data

DTE Outputs

DTE	Name	Baud rate
DTE 1	<input type="text"/>	9600
DTE 2	<input type="text"/>	9600
DTE 3	<input type="text"/>	9600
DTE 4	<input type="text"/>	9600

UDP Outputs

Name	IP	Port	Interface	VLAN
<input type="text"/>	0.0.0.0	15000	Data 1	0

To configure the ancillary data outputs:

1. Navigate to the page **Ancillary Data**.
 2. Enter name for the DTE outputs and set a baud rate.
 3. To add UDP outputs for ancillary data, click .
 4. Configure the parameters for the UDP outputs.
 5. Click **Save**.
 6. Navigate to the page **Codec**.
 7. In the tab **Ancillary Output**, assign sources to the ancillary data outputs. You can either select a specific ancillary data source or one of the decoder audio outputs. If one of the decoder audio outputs is selected, then the SAT-4d outputs the ancillary data of the currently active main or backup source.
 8. Click **Save**.
- ✓ The ancillary data are now assigned to outputs.

Parameters

- Name** Enter a name for the output for better reference.
- IP** Enter the IP address. This can be a multicast IP.
- Port** Specify the port for ancillary data via UDP.
- Interface** Select the [Data] interface to be used.
- VLAN** If the selected [Data] interface is an interface with VLAN, then select the VLAN to be used.

7.5 Defining switch criteria

The SAT-4d decoder can automatically switch between alternative sources as a redundancy solution in case of failure. The decoder receives and processes all enabled input sources from the encoder but only outputs the audio signal of the highest priority that is error-free (main source – backup 1/2/3). Additionally to the global switch criteria, you can define switch criteria for individual sources that override the global switch criteria.

You can enable the following switch criteria for input sources. The availability of switch criteria depends on the selected input source.

No input data	The SAT-4d will switch to the next input source if no signal is available in the activated IP input [Data].
Packet jitter	The SAT-4d will switch to the next input source if the packet jitter exceeds the set value.
Packet loss	The SAT-4d will switch to the next input source if packet errors are detected in the input signal over the activated IP input [Data].
No decoder output	The SAT-4d will switch to the next input source if the decoder does not output any data.
Audio silence detection	The input source will be switched to the next backup source if silence in the audio signal of the input stream is detected.
AES/EBU no signal	The input source will be switched to the next backup source if no signal is detected in the active input.
RF Level	The SAT-4d will switch to the next input source if the frequency is below the set value.
C/N	The SAT-4d will switch to the next input source if the carrier-to-noise ratio falls below the set value.
TS Sync	The SAT-4d will switch to the next input source if the transport stream is not synchronized.

To define global switch criteria for each audio input type:

1. Navigate to the page **Switch Criteria**.
 2. Click on the tab of the input source for which you want to define switch criteria.
 3. If any of the listed criteria should be monitored, enable the corresponding switch.
 4. In the field **Value**, enter the threshold above or below which the input source should be switched.
 5. For each enabled criterion, define the delay time **T1** for switching release. After this delay time, the input source switches to the next backup source.
 6. For each enabled criterion, define the delay time **T2** for switching end. After this delay time, the input source switches back to the previous source, if its signal is good.
 7. Click **Save**.
- ✓ The SAT-4d now automatically switches to the next good input source. For some switch criteria, you can set an alarm (see 9.1 Setting up alarms).

To define individual switch criteria for a specific input source:

1. Navigate to the page Codec.
2. Click **Edit** on the input source for which you want to define individual switch criteria.
3. Select the **Switch criteria** tab.

4. Toggle the switch **Override global switch criteria**.
 5. Define the individual switch criteria.
 6. Click **Save**.
- ✓ The switch criteria for this input source now override the global switch criteria.



On the page Codec, the switch criteria scope (SCS) of an input source is indicated with  for global and with  for individual.

7.6 Setting up dual streaming

Dual streaming is the simultaneous transmission and reception of 2 identical IP streams that come from the same encoder. This allows a seamless exchange of IP packets in case of errors: If the main stream drops packets, then the decoder immediately replaces them using the packets from the second stream. Ideally, the two streams use different networks, so one stream is still available in case of the other network failing. Alternatively, it is possible to send both streams over the same network, with one stream being slightly delayed by setting up a send delay for it. Lost packets in the primary stream can be replaced in case of a burst error by using a dejitter buffer. The downside of using one network for both streams is that both streams will be affected in case of the network failing.

To set up dual streaming:

1. Set up dual streaming in the input source settings. For more information, see 6.1 Input source settings.
 2. To use the input source, select it in the source assignment.
- ✓ Dual streaming is now enabled in the SAT-4d.

7.7 Setting up a buffer

The SAT-4d is equipped with an audio buffer and a dejitter delay for IP.

The audio buffer is a delay buffer for decoded audio. It saves decoded audio to output it in case of failure. The SAT-4d can use this time buffer, for example, to switch to the backup source or external source.

The dejitter delay for IP transforms the variable delay into a fixed delay. It holds the first packet received for a period of time before it sends it out to the decoder. This time period is necessary for reordering the packets and to compensate jitter.

When using the SAT-4d, there are different stages where delay is introduced during processing for security (e.g. FEC or dejitter delay). For uninhibited operation, make sure that delay settings are in a save range.

For a basic setup, delay is calculated in the following matter:

Encoder processing delay + transmission delay on IP network + decoder processing delay

Encoder delay is typically < 5 ms. Transmission delay on the IP network can vary by a large degree, depending on the network. Decoder processing delay needs to be broken down into multiple stages:

Dejitter/Reorder or FEC output delay + additional delay + decoder processing delay

If no FEC is used, you can use a dejitter/reorder buffer which will add delay in the length it is set up to. If FEC is used, there is a minimum delay that is required for safe operation (in the length of two full FEC matrices). Any delay on top of that is used for additional dejittering reordering of the input stream, as the FEC also includes this task as well. If the user setting is too small, it is overwritten internally to ensure safe operation. The current active setting to each decoder can always be viewed on the page **Overview** in the block "Details – Decoder". You can use the additional delay setting to further delay the output up to 1000 ms. The decoder will also have a small delay of < 5 ms.

Recommended default buffer configuration: Packet reorder delay: 100 ms, Audio delay: 100 ms

The minimal needed additional buffer sizes depend on the selected FEC Mode (Row x Col):

FEC Mode (2 x matrix size)	1x4 (8)	4x4 (32)	5x5 (50)	10x10 (200)
PCM (250)	0.03	0.13	0.20	0.80
MPEG1 Layer-2 (42)	0.19	0.76	1.19	4.76
MP3 (42)	0.19	0.76	1.19	4.76
AAC LC (47)	0.17	0.68	1.06	4.25
AAC HE v1 (24)	0.33	1.33	2.08	8.33
AAC HE v2 (24)	0.33	1.33	2.08	8.33

7.8 Receiving and decoding an AES67 stream

To receive and to decode AES67/Dante streams:

1. Navigate to the page **Codec**.
2. Create an input source profile for Elementary Streams.
3. Edit the input source profile. If a RAVENNA stream is available in the input stream, you can copy and save its settings. If no RAVENNA streams are available or the corresponding right is missing, configure the input source parameters manually.



Consider the default settings for SAP: SAP must be in Client/Server mode and use the correct receive address and port. RAVENNA uses 239.255.255.255 for SAP announcements.

4. Use exactly the following parameters:
 - **Encoder Format:** PCM
 - **Audio Mode:** Stereo
 - **Sampling Rate:** 48 kHz
 - **Sampling Width:** 24 Bit
 - **Endianness:** Big Endian
 5. Configure the remaining parameters with individual settings.
 6. Assign the configured input source to a decoder.
 7. Click **Save**.
- ✓ The decoder now receives an AES67/Dante stream.

8 Interface settings

8.1 Configuring the output settings

You can configure various settings for the output signals to ensure proper transmission and processing. The SAT-4d can either provide only digital channels or reduce the number of channels to also provide analog channels (L/R).

To configure the signal outputs:

1. Navigate to the page **Audio**.
 2. Select the device mode in the drop-down menu **Interface Signal Type**: digital only or analog/digital.
 3. Configure the parameters in the block **Audio Outputs**.
 4. Click **Save**.
- ✓ You have configured the signal outputs.

Parameters

Signal Type	Select the signal type for the output interfaces.
Digital Gain	Adjust the gain of the output signals. This is useful if the signal's level is too high or too low.
Sample Rate Converter	To convert the sample rate to a specific frequency, enable the Sample Rate Converter. For more information, see 7.2 Enabling the sample rate converter.
Sampling Rate	If the Sample Rate Converter is enabled, select the sampling rate.
Clock Source	Select the clock source for the Sample Rate Converter. To configure the external clock, see 8.2 Using an external clock source.
AES/EBU Mute	Enable this function to mute an output if no input source is available.

8.2 Enabling the sample rate converter

The SAT-4d is equipped with an internal sample rate converter (SRC) that converts stereo audio from one sample rate to another. The SAT-4d sample rate converter allows different rates at the digital AES/EBU inputs and outputs.

To enable the sample rate converter:

1. Navigate to the page **Audio**.
 2. Set the switch **Sample Rate Converter** to **ON**.
 3. Select a sampling rate in the dropdown menu.
 4. Click **Save**.
- ✓ The sample rate converter generates an exact sampling rate in the input/output audio.



The configured sample rate and sample width must be correct and correspond to the real values of the signal!

Sample processing with enabled Sample Rate Converter:

- The SAT-4d transports the decoded audio samples (PCM) through the sample rate converter (SRC) to the output.
- The sample rate converter generates the exact sampling rate for the output, which was configured in the web interface.
- In the SRC input, the jitter of the sampling rate is converted into a constant determined sampling rate for the output.

Sample processing without enabled Sample Rate Converter:

- The SAT-4d transports the decoded audio samples (PCM) directly to the output interface without converting the sample rate.



According to the AES-3 standard, data jitter varies between max +/- 20 ns. Depending on the bit depth, the signal-to-noise ratio has a better quality if the SRC is enabled.

During startup, the sampling frequency can vary up to +/- 20 ns according to the AES/EBU standard. After complete startup of the sample rate converter, the sampling frequency varies less.

8.3 Setting the critical level marker

The audio level of the inputs and outputs is displayed on the overview page. You can set the critical level marker to specify when the bar should turn orange.


Critical Level Marker	
Analog Threshold:	<input type="text" value="6.0"/> dBu
Digital Threshold:	<input type="text" value="-9.0"/> dBFS

To set the critical level marker:

1. Navigate to the page **Audio**.
 2. In the block **Critical Level Marker**, define the threshold above which the bar should turn orange.
 3. Click **Save**.
- ✓ The bar indicating the audio level of the inputs and outputs now turns orange whenever the audio level is above the set value.

8.4 Changing the headphone volume

The input signal can be monitored via the headphone interface.



To change the volume of the headphone output:

1. Navigate to the page **Headphone**.
 2. In the block **Headphone**, select the source for the headphone output.
 3. Set the volume for the headphone output in a range from -40.0 to 0.0 dB.
- ✓ The volume of the headphone output is now adjusted.

8.5 Viewing the GPI status

The SAT-4d is equipped with 8 GPI contacts. The inputs can be used for remote control (in combination with remote control software).

- To actuate a GPI, pull the corresponding control pin electrically to ground (pin 9). The resulting control current is less than 5 mA.
- To view the status of the GPIs, navigate to the page **GPI**.

8.6 Configuring GPO settings

The SAT-4d has 8 GPOs. You can use the relays for alarms of the monitoring function. For more information, see 9.1 Setting up alarms.

To configure the GPO settings and view the status of the GPOs:

1. Navigate to the page **GPO**.
 2. To invert a GPO, enable the corresponding switch.
 3. Select the source for the GPO switch in the field **Source**. Only GPOs that are selected for the source **Alarm** can be used to indicate a triggered alarm.
 4. If you set GPIO Tunneling as the source, then select the audio to be used for this function.
 5. Click **Save**.
- ✓ You have configured the GPO settings.

GPO

State / Configuration

	State	Inverted	Source	Audio		State	Inverted	Source	Audio
GPO 1	●	<input type="radio"/> OFF	Alarm	Audio output 1	GPO 5	●	<input type="radio"/> OFF	Alarm	Audio output 1
GPO 2	●	<input type="radio"/> OFF	Alarm	Audio output 1	GPO 6	●	<input type="radio"/> OFF	Alarm	Audio output 1
GPO 3	●	<input type="radio"/> OFF	Alarm	Audio output 1	GPO 7	●	<input type="radio"/> OFF	Alarm	Audio output 1
GPO 4	●	<input type="radio"/> OFF	Alarm	Audio output 1	GPO 8	● A ● B	<input type="radio"/> OFF	Alarm	Audio output 1

The virtual LED **State** indicates the status of the GPOs (green: ON, grey: OFF). The state of a relay is ON if the alarm which is assigned to this relay is triggered.

8.7 Defining the use of the AUX interfaces

You can define for which purpose the AUX interfaces should be used. The [SYNC/AUX 1] interface can either be used as the ASI input or for 1PPS synchronization. The [AUX 2] interface is used as the ASI output.

AUX

SYNC / AUX 1 (Input)

Mode: SYNC 1PPS

AUX 2 (Output)

ASI Output enabled:

Output signal: Multiplex 1

Save

To configure the use of the AUX interfaces:

1. Navigate to the page **AUX**.
 2. In the block **SYNC / AUX 1 (Input)**, select whether this interface should be used for 1PPS synchronization or as an ASI input.
 3. In the block **AUX 2 (Output)**, enable the ASI output.
 4. In the dropdown menu **Output signal**, assign to each ASI output one TS Multiplex that is to be sent over ASI output.
 5. Click **Save**.
- ✓ The SAT-4d now uses the AUX interfaces as configured.

9 Audio over IP settings

9.1 Setting up SAP

The SAT-4d supports SAP (Session Announcement Protocol) for stream announcement.

Prerequisite: You are logged in as an admin.

To set up the SAP connection:

1. Navigate to the page **SAP**.
 2. Configure the parameters.
 3. Click **Save**.
- ✓ You have set up the SAP connection.

Parameters

Mode	To enable SAP, select the service mode. "Client/Server" is recommended.
Announce interval	Enter the time interval between sending SAP announcement.
Multicast loop	Multicast loop to makes the SAT-4d receive its own SAP announcements. The default setting is OFF.
Receive address and port	Set the multicast address and port to receive SAP announcements.
Ethernet port	Select the [Data] interface for transmission of SAP announcements in the dropdown menu.
Bandwidth limit	To avoid overhead, set a bandwidth limit for SAP announcements.
Destination address and port	Set the destination multicast address and port for SAP announcements.

9.2 Using an external clock source



This option is only available if either of the rights *SFN* or *SPN* is enabled or if the device is equipped with a GPS module.

You can synchronize the SAT-4d with an external clock. Precise synchronization of time across devices on a network is critical to avoid audio distortion or loss of quality. By using an external clock source, audio codecs can ensure that they are operating with the same timebase, allowing them to maintain a consistent audio stream. By keeping all devices synchronized to an external clock source, audio codecs can ensure that their output remains high-quality and reliable. You can configure 1 main and up to 2 backup clocks.

External clock

<p>Main</p> <p>External Clock Source: <input type="text" value="NTP"/></p> <p>Switch criteria</p> <p>NTP quality rating OK</p> <p>T1: <input type="text" value="30"/> s</p> <p>T2: <input type="text" value="30"/> s</p>	<p>Backup 1</p> <p>External Clock Source: <input type="text" value="1PPS"/></p> <p>Switch criteria</p> <p>1PPS signal present</p> <p>T1: <input type="text" value="30"/> s</p> <p>T2: <input type="text" value="30"/> s</p>	<p>Backup 2</p> <p>External Clock Source: <input type="text" value="none"/></p>
--	---	--

Note:
The device continues to work in free-running mode with the internal clock in case all configured external clock sources fail.

To synchronize the SAT-4d with an external clock:

1. Navigate to the page **External Clock**.
 2. Select an external clock source for the main and backup clock sources.
 3. Configure the parameters for the main and backup clock sources.
 4. Configure the switch criteria for the main and backup source. The configurable criteria may vary depending on the selected clock source.
T1 is the delay time for alarm trigger. **T2** is the delay time for alarm end.
 5. Click **Save**.
- ✓ The SAT-4d is now synchronized with an external clock. You can view the status information of the external clock on the page **Overview**. To use the external clock as the clock source for the audio outputs, see 7.1 Configuring the output settings.



In case all configured external clock sources fail, the device will continue to work in free-running mode using the internal clock.

Parameters - PTP

- Domain Number** Enter the domain number.
- PTP Interface** Select the Ethernet interface to use for PTP.
- PTP Unicast** If PTP Unicast is enabled, enter the unicast address.

9.3 Configuring Livewire settings



This option is only available if the right *Livewire* is enabled.

Livewire is an audio-over-IP system used for routing and distributing broadcast-quality audio. The livewire routing protocol is used to route audio as well as GPIO ports.

Livewire

<p>General</p> <p>Routing Protocol: <input checked="" type="checkbox"/> ON</p> <p>Hardware identification: <input type="text" value="0"/></p> <p>Ethernet: <input type="text" value="Data 1"/></p>	<p>GPIO</p> <p>Enable: <input checked="" type="checkbox"/> ON</p> <p>Ethernet: <input type="text" value="Data 1"/></p> <p>Name (GPIO 1-5): <input type="text" value="GPIO 1"/></p> <p>Name (GPIO 6-8): <input type="text" value="GPIO 2"/></p>	<p>Advertisement</p> <p>Enable: <input checked="" type="checkbox"/> ON</p> <p>Address: <input type="text" value="239.192.255.3"/></p> <p>Ethernet: <input type="text" value="Data 1"/></p> <p>Advertising port: <input type="text" value="4001"/></p> <p>Configuration port: <input type="text" value="4000"/></p>
---	---	---

Prerequisite: You are logged in as an admin.

To configure livewire settings:

1. Navigate to the page **Livewire**.
 2. Enable **Routing Protocol**.
 3. Configure the parameters.
 4. Click **Save**.
- ✓ You have configured the livewire settings.

Parameters

- Hardware identification** Enter the hardware ID.
- Ethernet** Select the [Data] interface to be used.

- GPIO** Assign names to [GPO 1-5] and [GPO 6-8].
- Advertisement** Enter the ports for Livewire Advertising and for its configuration.

9.4 Monitoring audio via Live Listening



This option is only available if the right *Live Listening* is enabled.

Activated input sources of the decoder as well as audio outputs can be monitored via Live listening. Live Listening enables you to listen "live" to any of the audio input sources as well as the audio outputs directly over the SAT-4d web interface. The SAT-4d is equipped with an adjustable bit rate encoder that can encode the input audio signal in five different formats. You can manually set up the parameters for audio encoding depending on the bandwidth available for data distribution.

Prerequisite: You have already configured the input sources and assigned them to the encoder and decoder.

To set up audio monitoring via Live Listening:

1. Navigate to the page **Live Listening**.
2. Configure the parameters.
3. Set the switch **Activation** to **ON**.
4. Click **Save**.
5. In the banner, select an available audio source from the dropdown menu **Live Source**.



6. To change the playback volume, click the green volume levels.
 7. To start streaming, click the play button.
- ✓ The SAT-4d now plays the audio over the web interface.

Parameters

- Port** Enter the port number for streaming.
The URL for Icecast streaming is "IP address of the device:streaming port". The standard port for live streaming is 8000. Example: `http://192.168.12.23:8000`.
- Encoder Format** Select an audio format for streaming.
- Audio Mode** Select a stereo or mono audio mode.
- Sampling Rate** Select a sampling rate for streaming.
- Bitrate** Select a bit rate for the selected audio format quality.

10 System settings

10.1 Setting up alarms

You can set several alarms that trigger in case of defined events. You can monitor the following:

Temperature	Alarm is triggered if the device temperature exceeds the configured value.
Power failure	Alarm is triggered in case of an error in a power supply unit.
LAN Link	Alarm is triggered in case of an error in Ethernet data communication.
1 PPS clock status	Alarm is triggered if 1 PPS signal is not present.
PTP clock status	Alarm is triggered if PTP signal is not present.
NTP clock status	Alarm is triggered if NTP server is available.
AES/EBU No Signal	Alarm is triggered if no decoded digital audio is available in the audio input.
AES/EBU CRC Error	Alarm is triggered if a cyclic redundancy check error is detected.
Silence Detection	Alarm is triggered if the device detects silence in the left and/or right channel of the audio output.
No Input Data	Alarm is triggered if no input data is detected.

To set up alarms:

1. Navigate to the page **Alarm**.
 2. For each alarm, configure the corresponding parameters.
 3. Click **Save**.
- ✓ Enabled alarms will now be saved in a log entry and signaled over SNMP, LED or GPO if triggered.

Parameters

Enable	Enable or disable an alarm.
Priority	Select the priority of the alarm message.
Values	Enter the value below or above which the alarm triggers.
T1	Set the delay time for alarm trigger.
T2	Set the delay time for alarm end.
SNMP, LED, GPO	Enable the corresponding switch if the alarm should be signaled by SNMP traps, an LED or GPO switch. The corresponding GPO must be activated for the source "Alarm" (see 7.6 Configuring GPO settings).

10.2 Entering device information

For better identification of the SAT-4d, you can enter device-specific data.

1. Navigate to the page **Global**.
 2. Configure the parameters in the block **System info**.
 3. Click **Save**.
- ✓ The saved information is now displayed in the banner.

Parameters

Name	Enter the name of the device for better reference.
Location	Enter the location of the device.
Description	Enter further important information on the device.

10.3 Setting up session timeout

Session timeout is a security feature that automatically logs out the user after a period of inactivity. You can define the period of inactivity or disable session timeout.

1. Navigate to the page **Global**.
 2. In the field **Session timeout**, enter the value in minutes for the period of inactivity necessary to automatically log out the user. Enter “0” to disable this function.
 3. Click **Save**.
- ✓ You will now be automatically logged out after the set period of inactivity.

10.4 Changing the title of the browser tab

You can change the title of the browser tab to display the information you need for better reference.

1. Navigate to the page **Global**.
 2. In the field **Browser Tab Title**, enter the information you want to display. You can use variables for specific information. Variables will update automatically if the corresponding information changes. View the possible variables by hovering over the input field.
 3. Click **Save**.
- ✓ The title of the browser now displays the configured information.

10.5 Updating the firmware with a file

You can upload ARM firmware stored locally and activate it via the web interface. Alternatively, you can load a firmware file from a USB stick – either manually or automatically.

To load a firmware file via the web interface:

1. Navigate to the page **Global**.
 2. In the block **Firmware** update, click **Browse/Drop file**.
 3. Select the firmware file you want to upload.
 4. Click **Upload** to upload the firmware file. The upload may take a while. Do not interrupt this process.
 5. After a successful upload, follow the prompt to restart the device.
- ✓ After the reboot, the new firmware is active.

To manually install firmware from a USB stick via the LCD menu:

1. Insert a USB stick with the firmware file into the [USB] port.
 2. Use the jog wheel to select **Config menu** → **System** → **Global** → **Update firmware from USB**.
 3. Select the firmware file you want to upload.
 4. Select **Update**. The installation may take a while. Do not interrupt this process.
 5. Select **OK** to reboot the device.
 6. Remove the USB stick from the device.
- ✓ After the reboot, the new firmware is active.

To automatically install firmware from a USB stick:

1. Create a folder named "autoupdate" on the USB stick.
 2. Place the firmware file in the "autoupdate" folder. Make sure that the folder only contains one firmware file.
 3. Insert the USB stick into the [USB] port.
 - The device automatically finds the firmware file on the USB stick. If the firmware version of the file differs from the currently installed one, the device automatically installs the new firmware. The installation may take a while. Do not interrupt this process.
 4. Select **OK** to reboot the device.
 5. Remove the USB stick from the device.
- ✓ After the reboot, the new firmware is active.

10.6 Checking for updates

You can check for updates and install them, if available. You can also view the release notes and details about the available updates. Additionally, it is possible to download the firmware file to install at a later point of time.

To install an available update:

1. In the menu **Support**, click **Check for updates**.
 - The window **Available Firmware Versions** opens.
 2. Select the update you want to install.
 - The dialog window **Firmware Update** opens.
 3. Click **Yes, update now**. The update may take a while. Do not interrupt this process. Since the device reboots during this process, you will be logged out.
- ✓ The firmware is now updated.



In the window **Available Firmware Versions**, firmware bundles that are newer than the currently installed one are marked with ★. Important updates are marked with !. Click **Open** to view the change notes and details about a bundle version. To download a firmware bundle for later installation, click .



In the window **Available Firmware Versions**, you can enable an **automatic update check** every 24 hours. If a new update is available, it will be indicated by the ★ icon next to the **Check for Updates** menu item. You can also enable a notification dialog that informs you of any new updates.

10.7 Setting up rights

Some functions of the SAT-4d are optional. To use these functions, you must activate additional rights by uploading a rights file. To receive rights files, please contact your 2wcom sales representative.

1. Navigate to the page **Global**.
 2. In the block **Rights**, click **Browse/Drop file**.
 3. Select the rights file (*.2wcom_key) you want to upload.
 4. Click **Upload**. The upload may take a few minutes. Do not interrupt this process.
 5. After a successful upload, follow the prompt to restart the device.
- ✓ The new rights will be active after restart. You can view the current rights in the block **System information**.

10.8 Uploading and activating an SSL certificate

An SSL certificate is a digital certificate that provides authentication for a website and enables an encrypted connection.

To upload and activate an SSL certificate:

1. Navigate to the page **Global**.
 2. In the block **SSL-Certificate**, click **Browse/Drop file**.
 3. Select the SSL certificate file (*.pem) you want to upload.
 4. Click **Upload**. The upload may take a while. Do not interrupt this process.
- ✓ You have uploaded an SSL certificate.

10.9 Saving settings to a local file

You can download the current settings and save them as a file. You can upload this file later to restore the settings or upload it to another device to copy the settings.

1. Navigate to the page **Global**.
 2. In the block **Settings download**, click **Generate**.
 - A file is being created. This may take a few seconds.
 - The download option with the time and date of file creation appears.
 3. Click **Download**.
 4. Save the file to a location of your choice.
 5. Click **Save**.
- ✓ You have saved settings to a local file. To upload and activate the settings stored locally, see 9.10 Loading settings from a file.

10.10 Loading settings from a file

You can upload a settings file to restore previous settings or copy the settings from another device. You can do this either via the web interface or the LCD menu. You can load the settings either without or including IP settings such as IP addresses and VLANs. This enables you to easily swap out a device. Note that if you load settings including IP via the web interface, you will lose the connection to the device due to the new IP address. For information on how to generate a settings file, see 9.9 Saving settings to a local file.

To load a settings file via the web interface:

1. Navigate to the page **Global**.
 2. In the block **Settings update**, click **Browse/Drop file**.
 3. Select the settings file you want to upload.
 4. Click **Upload** to upload the settings file. The file upload may take a while. Do not interrupt this process.
- ✓ The new settings are now active. If you chose to also load the IP settings, the device now has a new IP address.

To load a settings file via the LCD menu:

1. Insert a USB stick with the settings file into the [USB] port.
 2. Use the jog wheel to select **Config menu** → **System** → **Settings** → **Load from USB** or **Load from USB (incl. IP)**.
 3. Select the settings file you want to upload.
 4. Select **Upload**. The file upload may take a while. Do not interrupt this process.
- ✓ The new settings are now active. If you chose to also load the IP settings, the device now has a new IP address.

10.11 Generating and downloading a diagnostic report

In case of any problems or failures, you can generate and download a diagnostic report to send to 2wcom.

To generate and download a diagnostic report:

1. Navigate to the page **Global**.
 2. In the block **Diagnostic Report**, select the time period for which the device captures all activities.
 3. Click **Generate**. A file is being created. This may take a while. Do not interrupt this process.
 - The download option with the time and date of file creation appears.
 4. Click **Download**.
 5. Save the file to a location of your choice.
- ✓ You have generated and downloaded a diagnostic report.

10.12 Uploading a debug script

To identify a specific error, you can upload a debug script that you have received from 2wcom. Depending on the expected error, the debug script monitors extra status information and records the incoming data. When the error occurs, the recording stops and a debug.log file is generated which contains all information that 2wcom needs to fix it.

To upload a debug script:

1. Navigate to the page **Global**.
 2. In the block **Debug Report**, click **Browse/Drop file**.
 3. Select the debug script file (*.upd) you want to upload.
 4. Click **Upload**. The upload may take a while. Do not interrupt this process.
 5. To start the debugging process, click **Start**. This may take a while. Do not interrupt this process.
 - When an error occurs, the script is automatically stopped. A download link for the debug.log file appears.
 6. To download the debug.log file, click on the link.
 7. Send the file to your 2wcom contact person.
- ✓ 2wcom can now identify the error and determine further action.

10.13 Rebooting the device

To reboot the device:

1. Navigate to the page **Global**.
 2. In the block **Control**, click **Now** in the field **Reboot Device**.
- ✓ The device restarts. After the restart, you will have to log in again.

10.14 Restoring factory settings

Restoring the factory settings will delete all configurations that were made by a user except for the IP address of the CTRL interface. This also applies to the access accounts.

To reset the device to factory settings:

1. Navigate to the page **Global**.
 2. In the block **Control**, click **Now** in the field **Load Factory Settings**.
- ✓ You have restored the factory settings.



10.15 Accessing the recovery mode via reset pin hole

If you cannot access the SAT-4d via the web interface, you can reboot the device using the reset pin hole. You can also use the reset pin hole to access the recovery mode in which you can flash the device or restore factory settings.

- To restart the device, press the reset button for a second.
1. To access the recovery mode, press the reset button for a few seconds until all LEDs on the front panel turn off and only power LED starts flashing quickly.
 - The device starts in recovery mode.
 2. Access the recovery web interface by entering the IP address of the device into a web browser. In recovery mode, you can upload and activate firmware, reset the system to factory settings or reboot the device.



3. After flashing or resetting the device, reboot the device by clicking **Reboot**.
- ✓ After a few seconds, the device will be ready for operation.

10.16 Setting the time and date

You can set the time, time zone and date of the internal clock.

1. Navigate to the page **Time**.
 2. In the block **Local time**, select the present time zone in the dropdown menus.
 3. Click **Save**.
 4. In the block **Time and date settings**, enter the current date and time.
 5. Click **Save**.
- ✓ You have set the time and date. The current time and date of the internal clock is shown in the field **Present local date and time**.

10.17 Changing login data

The default accounts are a read-only access (Guest account), a full access without a permission to manage the user accounts (Manager account), and a full access (Admin account). The user account SFTP service is used only for the access from an external SFTP client for uploading audio files and saving them in the internal storage.

Change the login data after the first login to the web interface.

The default login data for the first login are (case sensitive):

- Guest account: “guest”/ “guest”
- Manager account: “manager”/ “manager”
- Admin account: “admin”/ “admin”
- FTP service: “sftpuser”/ “sftpuser”

To change the login data:

1. Log in as an admin.
 2. Change the login data for an account in the corresponding block and repeat the new password.
 3. Click **Save**.
- ✓ You have changed the login data.

10.18 Adapting the access for user accounts

You can configure the access to certain web interface pages for the manager and guest accounts.

Prerequisite: You are logged in as an admin.


To adapt the access for manager and guest accounts each individual SAT-4d menu:

1. Navigate to the page **User**.
 2. Click on the tab **Menu Access**.
 3. Enable or disable the access to the separate menus by setting the corresponding switch to either **ON** or **OFF**.
 4. Click **Save**.
- ✓ The new access configuration is now active.

11 Status information

11.1 Status LEDs

The SAT-4d is equipped with 4 status LEDs on the banner of the web interface that display the status of the inputs, outputs, power supply and alarms.




The following table displays the meaning of each LED:

LED	Color	Meaning
Power		All supply cords are connected and the power supply is OK.
		Toggles (green/red) if only one power supply is connected or OK.
Warning		LED is off if no alarms are triggered.
		At least one alarm is triggered.
Input		No input monitoring alarms are enabled.
		Input monitoring alarms are enabled and all inputs are OK.
		One or more inputs are bad, but at least one is good.
		All inputs are bad.
Output		No decoder output monitoring alarms are enabled.
		Output monitoring alarms are enabled and all outputs are OK.
		One or more outputs are bad, but at least one is good.
		All outputs are bad.

11.2 General overview

Overview page

The page **Overview** gives you general information on the status of your SAT-4d. The appearance of this page might differ depending on the activated rights, built-in modules and settings.



The audio levels of the inputs and outputs are displayed in the left block. To change the threshold above which the bar turns orange, see 7.3 Setting the critical level marker.

The block **Status** gives general device-specific information as well as information on the ethernet interfaces.

Decoder Status

To get a quick and detailed overview, you can view the current status of the decoder and the incoming data. To view the decoder status, navigate to the page **Overview** and click on the tab **Codec**.

In the block **Decoder**, you can see the status of the currently active decoders:

- Green: Enabled
- Gray: Disabled
- Red: Error

- To view more details on a decoder, click on the corresponding panel.
 - The **Details** view below the block **Decoder** now displays the status of the decoded audio.
- To reset the counters in the status fields, click **Reset Counters**.

The blocks display the following counters:

IP block	Missed indicates packets lost for the corresponding RTP receiver. This is the main error information when neither RIST, FEC, nor dual streaming are active.
FEC block	Recov. indicates the number of packets that were recovered by FEC. If dual streaming is active, then the same FEC is used on both IP connections. Unrecov. indicates the number of packets that could not be recovered. This is the main error information if FEC is active.
RIST block	Requested indicates the number of packets that are lost or late on the receiver side. These packets are requested for retransmission. Retransmitted indicates the number of packets that were retransmitted by the sender. Unrecovered indicates the number of packets that could not be recovered. This is the main error information if RIST is active.
Dual streaming block	Unrecovered indicates the number of packets that could not be recovered. This is the main error information if dual streaming is active.

The following abbreviations may appear in the decoder status overview:

SR	Sampling rate
-----------	---------------

SW	Sampling width
FEC	Forward error correction
Err	The number of errors in the decoder (e.g. failed samples, no audio, PER)
PER	Packet error rate of the input stream

External Clock Status

If an external clock is used, then it is displayed as on the page **Overview**. The tab **External Clock** gives quick status information on the external clock. This block shows the active clock source and the configured backup sources as well as their status information. For more information on the NTP servers, see 10.5 NTP Status.



System Information

The page **Global** gives specific information on the device, such as the uptime and time of the last boot, serial number, activated rights and software version. The current version of your SAT-4d is the **Bundle Version**.

System information	
Present local date and time:	09. August 2022, 15:19:28
Last boot:	08. August 2022, 16:18:43
Uptime:	0 days, 23:00:47
Serial number:	460.000014
▼ Bundle version:	1.00-rc11
File/Recovery system version:	2.26 / 2.01
App version:	2.11.6
Webinterface version:	3.09
FPGA version:	1.10b28 / 0
System Controller version:	1.05
SNMP MIB version:	1.0 (SNMP MIB)
Kernel version:	2wcom-01.16-rt60
▶ Codec versions	
HW Revision XPS/IF:	1.02 / 1.10
Rights:	4 Channels, Ravenna, Livewire, TS Decoder, SRT Decoder, 4 Dolby Decoder, Live Listening, ES Input, Iccast Input, File Input, BISS
Missing rights:	
Open source acknowledgements:	Link

11.3 Device status

The page **Device** gives information on the current status of the hardware.

- The block **Mainboard** displays the voltages on the mainboard and the device temperature.
- The block **Fans** displays the speed of the fans.
- The blocks **Power Supply** display the status and type of the left and right power supplies. The colored bar indicates the status: green - ok, red - no power. If only one power supply module is built in, the only one block is displayed on this page.
- The block **Expansion Modules** displays built-in hardware options. If no expansion modules are built in, this block is not shown.



11.4 Ancillary data status

The status page **Ancillary Data** gives information on the status of the ancillary data inputs and outputs.


- The different Tabs display information on the DTE inputs and DTE outputs.
- The block **RAW Data** displays the data in the hexadecimal and ASCII code as well as the total bytes.
- The block **RDS/UECP Data** displays the information on the active RDS/UECP data as well as the total frames.
- To pause the data recording, click **Pause**.
- To clear the log, click **Clear**.

11.5 NTP Status

Navigate to the page **NTP Status** to view the status of the NTP servers used for time synchronization.

The first block gives information on the quality of the current synchronization. The SAT-4d always uses the best available source. The quality status of the current NTP server synchronization is displayed via a color-coded bar:

- green = the quality is good
- red = at least one of the listed data is bad



The list below explains the data that is displayed in this block:

- NTP Source** States whether an NTP source is available.
- Reference ID** The reference ID and IP address of the server to which the computer is currently synchronized.
- Ref time (UTC)** The time (UTC) at which the last measurement from the reference source was processed.
- Stratum** The stratum value indicates how many levels away the NTP server is from the primary reference source. Lower stratum values indicate a closer and more accurate clock source.
- Frequency** The rate by which the clock would be wrong if it were not corrected.
- Residual Frequency** Difference between what should be frequency according to the measurements from the reference source and the frequency that is currently used.
- Skew** The frequency offset to the clock standard.

- RMS Offset** The root-mean-square offset is a long-term average offset to the currently estimated time.
- Last offset** The time (UTC) at which the last measurement from the reference source was processed.
- Leap status** Normal: no leap second.
 Insert second: leap second will be inserted at the end of the month.
 Delete second: leap second will be deleted at the end of the month.
 Not synchronized: unknown status (no valid measurement was made).

The block **NTP Server Status** lists all NTP servers and gives detailed information on them. The status of the NTP server source is displayed via a color-coded bar:

- green = current best
- orange = combined
- red = not combined

NTP Server Status											
NTP Server 1											
Source State	Name/IP address	Stratum	Poll	Reach	LastRx	Measured Offset	Adjusted Offset	Estimated Error	Frequency	Freq. Skew	Standard Deviation
Current best	ntp4.lwcom.net	1	100 s	377	578	-201us	-275us	+/- 2921us	-0.068	0.162	218us
NTP Server 2											
Source State	Name/IP address	Stratum	Poll	Reach	LastRx	Measured Offset	Adjusted Offset	Estimated Error	Frequency	Freq. Skew	Standard Deviation
Not combined	mail.sebi.org	2	100 s	377	577	-792us	-792us	+/- 34ms	-0.180	0.281	141us
NTP Server 3											
Source State	Name/IP address	Stratum	Poll	Reach	LastRx	Measured Offset	Adjusted Offset	Estimated Error	Frequency	Freq. Skew	Standard Deviation
Combined	time.cloudflare.com	3	100 s	377	532	-276us	-276us	+/- 5891us	-0.039	0.255	206us
NTP Server 4											
Source State	Name/IP address	Stratum	Poll	Reach	LastRx	Measured Offset	Adjusted Offset	Estimated Error	Frequency	Freq. Skew	Standard Deviation
Not combined	217.160.114.150	2	100 s	377	171	-2939us	-2939us	+/- 86ms	+0.265	0.448	560us

The list below explains the data that is displayed in this block. For more information, visit chrony.tuxfamily.org/doc/4.1/chronyc.html

- Source State** Current best: the best source which is currently selected for synchronization
 Combined: other sources selected for synchronization which are combined with the best source.
 Not combined: any other source.
- Name/IP address** The name or the IP address of the source
- Stratum** The stratum value indicates how many levels away the NTP server is from the primary reference source. Lower stratum values indicate a closer and more accurate clock source.
- Poll** Polling interval, which is the frequency at which the device queries the NTP server for time updates.
- Reach** Indicates the reachability of the NTP server. This is a bitmask value that shows how successfully the device has been able to reach and communicate with the server.
- LastRx (Last Receive)** Shows how long ago the last good sample was received from the source.
- Measured Offset** The measured time difference between the local clock and the NTP server's clock at the time of synchronization.
- Adjusted Offset** This value represents the measured offset after any corrections or adjustments have been applied to align the local clock with the NTP server's time.
- Estimated Error** The total worst-case timing error accumulated between the stratum 1 server and the client.
- Frequency** This is the estimated residual frequency for the server.
- Frequency Skew** The frequency offset to the clock standard.
- Standard Deviation** This is the estimated sample standard deviation.

11.6 Internal storage status

You can upload audio files to the internal storage to use them e.g. as a backup input source.

The screenshot shows the 'Internal Storage' interface. On the left, the 'Data storage' section shows a progress bar at 6% and text indicating 5896.8 MB free of 6282.7 MB. On the right, the 'Upload' section has a text prompt 'Upload audio files (*.mp2, *.mp3, *.wav, *.aac)', a 'Browse / Drop file' button, and a 'No file selected' status with an 'Upload' button. Below these is a progress bar at 0%. At the bottom, the 'Audio files' section contains a table with columns for Filename, Date, Size, and a Delete button for each row.

Filename	Date	Size	
1khz_48ksps_6db.wav	24.06.2022 11:04:23	11 MB	Delete
backup file.mp2	08.08.2022 14:19:55	8.1 MB	Delete

To upload an audio file to internal storage:

1. Navigate to the page **Storage**.
 2. In the block **Upload**, click **Browse/Drop file**.
 3. Select the audio file (*.mp2, *.mp3, *.wav, *.aac) you want to upload.
 4. Click **Upload**. The upload may take a while. Do not interrupt this process.
 - The uploaded file is now displayed in the block **Audio files**.
- ✓ You have uploaded an audio file to the internal storage. The percentage of used storage is displayed in the block **Data storage**.

11.7 Log

The **event log** is a record of significant system events, such as system restarts and error messages, which are crucial for monitoring the performance of the device. These events have an alarm priority and may require immediate attention or action to resolve issues or ensure proper operation. See also: 9.1 Setting up alarms.

The screenshot shows the 'Event Log' interface with the 'Extended Log' tab selected. It features a search filter, operation and state indicators, and buttons for 'Auto Refresh', 'Download', and 'Clear'. The main area is a table of log entries.

No	Time	Priority	State	Message
887	2023-09-07 11:06:03	Informational		Successful login as Admin from 192.168.96.90
886	2023-09-06 13:15:14	Informational		Successful login as Admin from 192.168.99.120
885	2023-09-06 08:16:55	Informational		Successful login as Admin from 192.168.99.120
884	2023-09-05 14:07:24	Informational		Successful login as Admin from 192.168.96.90
883	2023-09-05 12:40:30	Informational	●	BNC Input 1: Silence Detection (Ref: 0.0, Level: 5.0 [dBu])
882	2023-09-05 12:40:02	Emergency	●	BNC Input 1: Silence Detection (Ref: 0.0, Level: -11.9 [dBu])

The **extended log** contains less critical information compared to the event log and is primarily intended to provide insights into general events. The log entries in the extended log are informational and do not carry alarm priorities, they are volatile and do not persist over restarts.

The screenshot shows the 'Event Log' interface with the 'Extended Log' tab selected. It features a search filter, operation and state indicators, and buttons for 'Auto Refresh' and 'Download'. The main area is a table of log entries.

No	Time	Source	Type	Message
54	2023-09-05 16:33:50	Default	RtpRxTimedOut	RTP Rx stream timed out from IP 192.168.101.72:52238, SSRC:0x00000000
53	2023-09-05 16:00:09	Default	RtpUnrecoveredPkt	RTP Rx 1 packet(s) unrecovered (eq. 3ms), 1st missed SEQ:36339
52	2023-09-05 16:00:09	Default	RtpMissedPkt	RTP Rx 1 packet(s) missed, 1st missed SEQ:36339 (from 192.168.101.72:52238)
51	2023-09-05 15:21:27	Default	RtpRxStart	Start RTP Rx from IP 192.168.101.72:52238, SSRC:0x00000000
50	2023-09-05 15:21:27	Default	RtpRxStart	Start RTP Rx from IP, SSRC:0x65ebd7cc
49	2023-09-05 15:21:11	Default	RtpRxTimedOut	RTP Rx stream timed out from IP 192.168.101.72:52238, SSRC:0x00000000
48	2023-09-05 15:21:00	Default	RtpRxStart	Start RTP Rx from IP 192.168.101.72:52238, SSRC:0x00000000

- To automatically refresh the page and immediately see new entries, toggle the switch **Auto Refresh**.
- To sort the log entries, click on the column header of the parameter by which you want to sort the entries. To reverse the order, click that header again.
- To search for a specific entry, enter a term into the search bar.
- To save the list to a log file, click **Download**.
- To delete all log entries, click **Clear**. Confirm your choice in the dialog window.

11.8 Priority of alarm messages

Priority	ID/Code	Definition
Emergency	0	System is unusable
Alert	1	Actions must be taken immediately
Critical	2	Critical condition
Error	3	Error condition
Warning	4	Warning condition
Notice	5	Normal but significant condition
Informational	6	Informative message
Debug	7	Debug-level message

In case of an alarm, an error report with the priority of the error will be sent to the Network Operations Center (NOC). The responsible second-level support will decide by means of this information how urgent the alarming case is and what measures are necessary. The event will be recorded in a log entry.

12 Further information

12.1 Maintenance and disposal

No special maintenance is necessary on the device. Do not use corrosive detergents on the device such as benzene, thinner, alcohol or acetone.

Remove dust on the housing of the device with a soft, dry cloth.

Electrical appliances do not belong in domestic waste. Dispose of the device in an environmentally friendly manner via suitable collection systems in accordance to the local regulations.

12.2 Troubleshooting, support and warranty

More often than not, it is only a small detail that has been overlooked and leads to a problem. Therefore, read the entire user manual carefully, as this will help you to understand, prevent and eliminate typical problems. Use the following table to self-check common error sources prior to contacting our support.

Report failures by email to support@2wcom.com. For a support request to 2wcom, please have the serial number of the device ready. You can find the serial number of your device on the page **Global** and on the sticker on the rear side of the device: "S/N xxx.xxxxxx".

For information on the warranty of 2wcom products, visit <https://www.2wcom.com/terms-and-conditions/>.

Problem	Possible Causes	Solution
Device does not turn on	<ul style="list-style-type: none"> Power cable is connected improperly Mains supply failure Blown fuse 	<ul style="list-style-type: none"> Check power supply cord. Make sure that the power plug is fully inserted. Check mains supply. Replace fuse by same type.
Device is not accessible via Ethernet	<ul style="list-style-type: none"> Network cable is not connected IP address/TCP port is unknown A device with the same IP address was connected a few minutes before. Thus, the ARP table still assigns the old MAC address to the IP address. 	<ul style="list-style-type: none"> Connect the network cable. Check IP address obtained from DHCP via LCD menu. The operation system refreshes the ARP table every few minutes. For an instant access to the device, reset the ARP table of your computer, e.g. by entering <code>arp-d</code> in the Windows command prompt.
Device does not respond		<ul style="list-style-type: none"> Reboot the device. Update the software.

12.3 Manufacturer

2wcom Systems GmbH
Am Sophienhof 8
24941 Flensburg
Germany

Phone (+49) 461 662830-0
Fax (+49) 461 662830-11
Email contact@2wcom.com
Web www.2wcom.com

© 2024

2wcom and the 2wcom logo are registered trademarks of 2wcom in Germany and other countries.

13 Technical details

13.1 Specifications



Technical details 1/3

Inputs

RF	F-female
Frequency	950 .. 2.150 MHz, step 1 kHz All LNB oscillator frequencies possible
Input level, impedance	-75 .. -20 dBm, 75 Ω
LNB Control	13 V vertical, 18 V horizontal, off 0 kHz low band, 22kHz high band
Noise figure	Typical 6dB, max. 12 dB

ASI

Data	MPEG2 TS- 270 Mbps
Connector	BNC - 75 Ω configurable to be either ASI input or 1PPS SYNC input (Option)

Gigabit IP

Data	MPEG TS or RTP, UDP, audio
Type	Auto switching 10/100/1000 BASE-T Unicast, Multicast

Redundancy Input

IP

Data	Option: Icecast / Shoutcast / HLS audio
Type	Auto switching 10/100/1000 BASE-T

Satellite modulation

Satellite tuner

DVB-S (EN 300 421)

Modulation/symbol rate	QPSK (1 .. 45 MSym/s)
FEC	Viterbi, Reed Solomon 1/2, 2/3, 3/4, 5/6, 6/7, 7/8

DVB-S2 (EN 302 307)

Modulation/symbol rate	QPSK, 8PSK, 16 APSK (1 .. 45 MSym/s) 32 APSK, 64 APSK (1.. 38 MSym/s)
-------------------------------	--

Modulation type	CCM
Frame type	Short, normal
Roll-off	0.20, 0.25, 0.35
FEC	LDPC, BCH 1/4, 1/3, 2/5, 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10
Transport Stream Processing	Single and multiple transport stream / Single and multiple generic stream
PL scrambling	ID 0... 262144
IF Filter bandwidth	Automatic selection
MPEG decoding	Acc. to ETSI TR 101 154
BISS-1,E descrambling	Optional

Tuner option (Low symbol rate)

DVB-S (EN 300 421)

Standard	QPSK (0.128 .. 45 MSym/s)
modulation/symbol rate	
Roll-off	0.35
FEC	Viterbi, Reed Solomon 1/2, 2/3, 3/4, 5/6, 6/7, 7/8



Technical Details 2/3

DVB-S2 (EN 302 307)

Standard	QPSK (128 kSym/s ..
modulation/symbol rate	35 MSym/s)
FEC	LDPC, BCH 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10
Modulation/symbol rate	8PSK (128 kSym/s ..
	31 MSym/s)
FEC	LDPC, BCH 3/5, 2/3, 3/4, 5/6, 8/9,9/10
Roll-off	0.20, 0.25, 0.35

Outputs

Gigabit IP

Data	MPEG TS or MPE
Connector	RJ45
Type	Auto switching 10/100/1000 BASE-T, Unicast, Multicast

ASI

Data	MPEG2 TS- 270 Mbps
Connector	BNC - 75 Ω

Audio decoder

Standard	MPEG 1/2 Layer 2, 3 Linear PCM G.711, G.722 Opus Ogg Vorbis MPEG 2/4 AAC LC MPEG 4 AAC LD/ELD/ ELD v2 MPEG 4 HE-AAC v1&v2 Extended HE-AAC (xHE-AAC), Enhanced aptX (E-aptX) Optional: Dolby codecs
Sample rates	kHz: 16, 22,05, 24, 32, 44.1, 48 (On request: up to 192 kHz)
Sample rate converter	8:1 (with bypass modes)

Your audio. Our solution.

Interfaces

Audio

Digital (out)	4x AES/EBU, 110 Ω bal., integrated XLR
Analog (out)	2x L/R, < 20 Ω bal., integrated XLR
Headphone (out)	L/R, < 10 Ω, 6,3 mm
Analog reference level	+9 dBu (max.+18 dBu) (output)
Digital reference input	selectable by user
Digital reference level	-9 dBFS
Digital level	Max. 0 dBFS (output)
Digital Silence detection	-90 ... 0 dBFS
Adjustable gain	-9 ... +6 dB
Dynamic range	16 Bit, > 89 dB 24 Bit, > 130 dB
Harmonic distortion	<0.05 % / <-66 dB (40 Hz .. 10 kHz)
Frequency response	Depends on sample rate – e.g. 48 kHz: 0,1 dB; 20 Hz ... 22,5 kHz

Ethernet

Data	Audio, serial data and GPIO transmission, controlling and setup functions
Connector	3x RJ45
Type	Auto switching 10/100/1000 BASE-T



Technical details 3/3

Serial

Interface	4x RS-232C (rear) / Optional: 8x RS232c via Sub D-15
Data	Private data, MPEG ancillary data, UECF/RDS (acc.to TR 101 154)
Transmission rate	1200 to 115200 baud, asynchronous
USB	1x USB 2.0 interface for service

Interfaces

Contact closure

Connector	26 pole sub-D male
Inputs	8 inputs
Outputs	7+1 floating relays 7 relays SPST (from A) 1 relay SPDT (from C) Optional: 24 relays DC: max. 30 V, 1 A, 10 W

Internal storage (option)

Data	internal audio files
Size	7 GB (optional 1000 GB)
Type	eMMC (optional SSD)

Time synchronization (optional)

PTPv2	Network synchronization according to IEEE 1588- 2008
SYNC/AUX 1	BNC – 75 Ω – 1PPS

Control & monitor

Ethernet

User interface	Integrated WebGUI, LCD display
Data	Control and setup functions
Optional	Private data, MPEG ancillary data (IRT)

USB

USB 2.0 interface for
service, configuration
and firmware updates

Protocol

2wcom NMS, HTTPS,
SNMP, UDP, RTCP, SRT
Secure Reliable
Transport, SFTP IGMP,
ICMP, NTP, DHCP, SNMP,
SSH, PTPv2, TCP (Icecast,
HLS)

Front panel

LCDisplay	Graphical, 264x64 pixel
Jog wheel	Impulse, enter button
4 Duo LEDs	Power, input, output, warning

General data

Power consumption	<20W
Case dimensions	19", 1 HU, Depth: 310 mm, Width: 424 mm, Front panel: 484 mm
Weight	< 5 kg
Material	Steel plate (aluminium-zinc coated)
Operating temp. range	0...+45°C
Storage temp. range	-40...+70°C
Languages	English

Power supply

Standard	1x internal, 90...260 VAC, 47...63 Hz, 1x power port (IEC power connector)
Optional version 1	Two internal redundant power supplies (90...260 VAC or 48 VDC), automatic switchover
Optional version 2	Two hot swappable redundant power supplies (90...260 VAC or 48 VDC), automatic switchover

Datasheet Version 13.07.2022


These data are subject to modifications and amendments. Errors excepted.

Your audio. Our solution.

13.2 Pin Layouts for DTE and GPIO

DTE


The pin assignment for DTE is as follows:



GPI

The SAT-4d has 8 GPI contacts that are housed in the same 26-pole D-sub male connector as the GPOs. The inputs can be used for remote control (in combination with remote control software).

The pin layout for GPI is as follows:



- To actuate a GPI, pull the corresponding control pin electrically to ground (pin 9). The resulting control current is less than 5 mA.


NOTICE Risk of equipment damage!


➤ The voltage on GPI contacts must not be negative or exceed +0.7 V

GPO

The SAT-4d has 8 GPO contacts that are housed in the same 26-pole D-sub male connector as the GPIs: 7 SPST relays (form A) and 1 SPDT relay (form C). You can use the relays for alarms of the monitoring function.

The pin layout for GPO is as follows:

GPO No.	Switch contacts	Switch type
1	RELA0, RELB0	SPST, NO
2	RELA1, RELB1	SPST, NO
3	RELA2, RELB2	SPST, NO
4	RELA3, RELB3	SPST, NO
5	RELA4, RELB4	SPST, NO
6	RELA5, RELB5	SPST, NO
7	RELA6, RELB6	SPST, NO
8		SPST



SPST: a simple on/off switch: single pole, single throw

SPDT: single pole, double throw

NO: normally open

NOTICE Risk of equipment damage!

- The relay contacts have a maximum load of 0.5 A at 30 V DC. Do not exceed these values.

14 Certificates and declarations



EC declaration of conformity

The manufacturer

2wcom Systems GmbH
Am Sophienhof 8
24941 Flensburg
Germany

hereby confirms that the product:

SAT-4d

in its conception, construction and form put into circulation is in accordance with all the relevant essential health and safety requirements of the following EC/EU directives as amended and the national laws and regulations adopting these directives:

- | | |
|---|---------------------|
| • Audio/video, information and communication technology equipment - Part 1: Safety requirements | EN IEC 62368-1:2018 |
| • Electromagnetic Compatibility (EMC) Directive | 2014/30/EU |
| • Low Voltage (LVD) Directive | 2014/35/EU |
| • Radio Equipment Directive (RED) | 2014/53/EU |
| • Restriction of Hazardous Substances (RoHS 2) Directive | 2011/65/EU |

This EC-declaration of conformity is the result of a test, which was accomplished in accordance with the standards EN 301489-1:2020-06, EN 300422-1:2022-05, EN 300422-2:2017-07, EN 55011:2022-05, EN 55032:2022-08, EN 55035/A11:2022-06, EN 61000-3-2:2019-12, EN 61000-3-3:2023-02, EN 61000-4-2:2009-12, EN 61000-4-3:2021-11, EN 61000-4-4:2013-04, EN 61000-4-5:2019-03, EN 61000-4-6:2014-08, EN 61000-4-11:2020, EN 61000-4-16:2016-10, EN IEC 63000:2018.

This declaration is no longer valid if the machine is modified without our consent.

2wcom Systems GmbH

April 3, 2024

